1.1 Introduction

This manual describes the operation and maintenance of the Schlumberger Wireline & Testing Systems mechanical services tools. It is intended for use by field engineers and technicians who operate and maintain these tools.

1.1.1 Scope

The scope of this manual includes the following tool strings:

- Standard Logging Tool String
- Combinable Tool String
- Heavy Duty Tool String
- Memory Tool String

1.1.2 Safety

Safety is the first consideration in all operations. Read and understand all safety instructions before operating any tool.

WARNING: Failure to follow safety instructions may result in serious injury or death.

- Always wear safety glasses and hard hats in the work area.
- Never exceed the rated working pressure of any component.
- Ensure all personnel are clear of the tool string before applying pressure.
- Use only approved lifting equipment and procedures.

CAUTION: Improper handling may damage tools and equipment.

- Do not drop tools or allow them to strike hard surfaces.
- Store tools in a clean, dry environment when not in use.
- Inspect all O-rings and seals before each run.

1.1.3 Tool Description

The mechanical services tools are designed to provide reliable operation in a wide range of downhole conditions. The tools are modular and can be combined in various configurations to suit the requirements of the job.

1.1.3.1 Standard Logging Tool String

The standard logging tool string consists of the following components:

Item	Description	Length (ft)	Weight (lb)
1	Cable Head	1.5	25
2	Weight Bar	5.0	150
3	Tension Device	3.0	75
4	Centralizer	2.0	40
5	Logging Sonde	12.0	350
6	Bull Nose	0.5	10

1.1.3.2 Combinable Tool String

The combinable tool string is assembled from individual components to suit the specific requirements of the job. Refer to the job program for the recommended configuration.

1.1.3.3 Heavy Duty Tool String

The heavy duty tool string is used in high-temperature or high-pressure wells. All components are rated for the maximum expected conditions.

1.1.4 Specifications

Parameter	Value
Maximum Temperature	350 °F
Maximum Pressure	20,000 psi
Maximum Diameter	3.625 in
Minimum Diameter	1.375 in
Maximum Length	40 ft
Maximum Weight	1,500 lb

1.1.5 Operating Limits

The operating limits of the tools are determined by the weakest component in the string. Do not exceed the limits of any component.

- Maximum tension: 10,000 lb
- Maximum compression: 2,000 lb
- Maximum bending moment: 5,000 ft-lb
- Maximum torque: 1,000 ft-lb

1.1.6 Maintenance

Regular maintenance is essential for reliable operation. Perform the following maintenance after each run:

1. Clean all components with solvent and dry thoroughly.
2. Inspect all O-rings and seals for damage or wear.
3. Replace any damaged or worn components.
4. Lubricate all O-rings and seals with grease.
5. Check all threads for damage and clean as necessary.

1.1.7 Troubleshooting

Problem	Possible Cause	Solution
Tool will not power on	Dead battery	Replace battery
	Faulty connector	Clean or replace connector
	Blown fuse	Replace fuse
Tool will not communicate	Faulty cable	Test and replace cable
	Faulty surface equipment	Test surface equipment
	Incorrect configuration	Check configuration
Tool will not pump	Plugged nozzle	Clean nozzle
	Faulty pump	Repair or replace pump
	Leak in system	Locate and repair leak
Tool will not set	Insufficient pressure	Increase pressure
	Faulty setting mechanism	Repair or replace mechanism
	Obstruction in tool	Remove obstruction

1.1.8 Spare Parts

A recommended spare parts list is provided with each tool string. Keep spare parts on hand to minimize downtime.

Part Number	Description	Quantity
1001-0001	O-ring, 2-1/2 in	10
1001-0002	O-ring, 3-1/2 in	10
1001-0003	O-ring, 4-1/2 in	10
1002-0001	Seal, piston	4
1003-0001	Battery, lithium	2
1004-0001	Fuse, 10 A	5

1.1.9 Glossary

Bull Nose — The lowest component in the tool string, used to guide the tool string into the hole.

Cable Head — The component that connects the tool string to the wireline cable.

Centralizer — A component that centers the tool string in the hole.

Sonde — The main logging component that contains the measurement sensors.

Weight Bar — A component that adds weight to the tool string to overcome friction and buoyancy.


Schlumberger
Wireline & Testing Systems
Mechanical Services Manual
Rev. 1.0
Section 1 - Introduction
Page 1-1
1.1 Introduction
1.1.1 Scope
1.1.2 Safety
1.1.3 Tool Description
1.1.4 Specifications
1.1.5 Operating Limits
1.1.6 Maintenance
1.1.7 Troubleshooting
1.1.8 Spare Parts
1.1.9 Glossary



Calibration Report

Calibration Date	10/8/18
Calibration Number	1
Calibration Type	Initial Calibration
Calibration Status	Passed
Calibration Error	0.00
Calibration Notes	

Calibration Points Calibration Report

Point Number	Value
1	0.00
2	100.00

CALIBRATION

Sensors	Readings	Target	Tol (Absolute)
Cal Point 1	0.00	0.00	0.0000
Cal Point 2	100.00	100.00	0.0000

Sensor File Calibration Report

Sensor Number	1
Sensor Serial Number	1
Calibration Date	10/8/18 08:45:37 (UTC)
Calibration Type	Initial Calibration
Calibration Status	Passed
Calibration Error	0.00
Calibration Notes	
Displayed Reading Before Calibration	0.0
Displayed Reading After Calibration	0.0
Operating Frequency	2.1 GHz
Operating Temperature	68 °F
Operating Pressure	0 PSIG
Operating Voltage	3.3 Volts