

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Date Received:
07/27/2011

Document Number:
2568494

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 46290 Contact Name: Kent Gilbert
Name of Operator: K P KAUFFMAN COMPANY INC Phone: (303) 825-4822
Address: 1675 BROADWAY, STE 2800 Fax: (303) 825-4825
City: DENVER State: CO Zip: 80202 Email: kgilbert@kpk.com
For "Intent" 24 hour notice required, Name: PRECUP, JIM Tel: (303) 726-3822
COGCC contact: Email: james.precup@state.co.us

API Number 05-123-08804-00
Well Name: JAMES S HALEY TRUSTEE B Well Number: 3
Location: QtrQtr: SESW Section: 2 Township: 1N Range: 68W Meridian: 6
County: WELD Federal, Indian or State Lease Number: _____
Field Name: SPINDLE Field Number: 77900

☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.074710 Longitude: -104.972420
GPS Data:
Data of Measurement: 07/27/2007 PDOP Reading: 2.0 GPS Instrument Operator's Name: R GORKA
Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems
☐ Other _____
Casing to be pulled: ☒ Yes ☐ No Top of Casing Cement: _____
Fish in Hole: ☐ Yes ☒ No If yes, explain details below
Wellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below
Details: Will test casing below 1000' and cut @ 1000' if test is good

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SHANNON	5132	5158			
SUSSEX	4682	4712			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	635	500	635	0	
1ST	7+7/8	4+1/2	10.5	5,286	300	5,286	3,600	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4600 with 2 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 275 sks cmt from 1050 ft. to 585 ft. in Plug Type: STUB PLUG Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Plan to cut casing at 1000', set tubing at 1050' and bring 275 sx cement up 50' into surface shoe.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kent Gilbert

Title: Operations Date: 7/26/2011 Email: kgilbert@kpk.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURN, DIANA Date: 7/28/2011

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 1/27/2012

1) Provide 24 hour notice of MIRU to Jim Precup at 303-469-1902 or e-mail at James.Precup@state.co.us. 2) For 1050' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug(must be 585' or higher). Leave at least 100' cement in the casing for each plug. 3) Properly abandon flowlines as per Rule 1103.

Attachment Check List

Att Doc Num	Name
2568494	FORM 6 INTENT SUBMITTED

Total Attach: 1 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Added lat/longs from Sundry dtd 2-25-08. Well completion report dtd 4-26-77.	7/28/2011 9:05:26 AM

Total: 1 comment(s)