

Koch Exploration Company, LLC  
Plug and Abandonment Procedure  
WRD Federal 2-27

Well Information:

API No: 05-103-09903  
Location: SENE Sec. 27-T2N-R97W  
Elevation: GL @ 6092'  
TD: 2300'  
PBSD: 2268'  
Perforations: 1330-2167'

Procedure:

1. MIRU service rig. Bleed off pressure. Remove wellhead and install BOP.
2. RIH with tubing to tag top of cement on CIBP set at 1200'.
3. RIH with tubing to 383'. Attempt to squeeze cement to surface. If unable to circulate, fill 4 ½" production casing with 35ft<sup>3</sup> of cement to surface.
4. Top job surface casing annuli if necessary.
5. Load out equipment and clean location.
6. Install dry hole marker as per Onshore Order #2.
7. Reclaim location as per BLM regulations.