

**FORM**  
**6**  
Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:  
400280421

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CINDY VUE  
 Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6832  
 Address: P O BOX 173779 Fax: (720) 929-7832  
 City: DENVER State: CO Zip: 80217- Email: CINDY.HURVUE@ANADARKO.COM

**For "Intent" 24 hour notice required,** Name: HICKEY, MIKE Tel: (970) 302-1024  
**COGCC contact:** Email: mike.hickey@state.co.us

API Number 05-123-34794-00 Well Number: 13N-22HZ  
 Well Name: SCHOMBER  
 Location: QtrQtr: NWNW Section: 22 Township: 2N Range: 66W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.129611 Longitude: -104.771145  
 GPS Data:  
 Date of Measurement: 09/01/2011 PDOP Reading: 2.5 GPS Instrument Operator's Name: CHRIS BOUB  
 Reason for Abandonment:  Dry     Production for Sub-economic     Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes     No    Top of Casing Cement: \_\_\_\_\_  
 Fish in Hole:  Yes     No    If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below  
 Details: After drilling the intermediate hole section to 7830' MD, 7" casing was run. The 7" casing became stuck at 7530' MD. We cemented the shoe with 500' of cement in the annulus. Then we came up to 6660' and perforated the casing. We cemented the casing through the perforations. The cement is from 6660' to 540'. We then attempted to go back to drilling. We cut 150' of new hole in the Niobrara. The drill pipe became stuck and hole conditions have continued to deteriorate.

**Current and Previously Abandoned Zones**

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	13+1/2	9+5/8	36	936	690	936	16	CALC
S.C. 1.1	8+3/4	7	26	7,530	122	7,530	6,658	CALC
S.C. 2.1	8+3/4	7	26	6,560	503	6,560	541	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7530 with 40 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 6760 ft. to 6560 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 (Cast Iron Cement Retainer Depth)

Set 30 sacks half in. half out surface casing from 995 ft. to 865 ft. Plug Tagged:   
 Set 10 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cindy Vue  
 Title: Regulatory Analyst II Date: \_\_\_\_\_ Email: Cindy.HurVue@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

### Attachment Check List

Att Doc Num	Name
400280918	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

User Group	Comment	Comment Date

Total: 0 comment(s)