

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400301297

Date Received:

07/02/2012

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: CHERYL LIGHT

Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP

Phone: (720) 929-6461

Address: P O BOX 173779

Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217-

Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: SCHURE, KYM

Tel: (970) 520-3832

COGCC contact:

Email: kym.schure@state.co.us

API Number 05-123-16051-00

Well Name: WARDELL

Well Number: 41-29

Location: QtrQtr: NENE Section: 29 Township: 3N Range: 65W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.202170

Longitude: -104.681440

GPS Data:

Date of Measurement: 02/14/2007

PDOP Reading: 2.4

GPS Instrument Operator's Name: Steve Fisher

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☒ Other SEE DETAILS FOR EXPLANATIONCasing to be pulled: ☒ Yes ☐ No

Top of Casing Cement: 6630

Fish in Hole: ☐ Yes ☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes ☒ No

If yes, explain details below

Details: It is not economic to perform the necessary safety preparations on the Wardell UPRR 41-29 for upcoming nearby horizontal wells.

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7307	7317			
NIOBRARA	7060	7070			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	685	340	685	0	CALC
1ST	7+7/8	2+7/8	6.5	7,489	255	7,489	6,630	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6800 with 2 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 6500 ft. to 6400 ft. Plug Type: STUB PLUG Plug Tagged: ☒

Set 110 sks cmt from 4700 ft. to 4400 ft. Plug Type: OPEN HOLE Plug Tagged: ☒

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 220 sacks half in. half out surface casing from 735 ft. to 0 ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST Date: 7/2/2012 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HOLLINSHEAD, RYAN Date: 7/3/2012

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 1/2/2013

- 1)Provide 48 hour notice of MIRU to Mike Hickey at (970) 302-1024.
- 2)Provide an "As Plugged" wellbore diagram identifying the specific plugging completed.
- 3)Cut and pull casing above the top of cement. Cement plug across casing stub from 6500' to 6400' assumes that the casing is cut off at 6450'. Adjust depths for this plug, as necessary, depending on the actual depth of the casing stub.
- 4)For the surface casing shoe plug, if not circulated to surface, tag plug and it must be at least 635' or higher.
- 5)If unable to pull casing contact COGCC for plugging modifications.
- 6)Any cement volumes provided in the Plugging Procedures shall be considered approximate and are for informational purposes only. Actual plugs shall be set to cover the full extent of the depths identified and cement volumes shall be adjusted accordingly to provide this required coverage.
- 7)Properly abandon flowlines as per Rule 1103.
- 8)Operator must tag plugs upon verbal request by the COGCC engineer or COGCC field inspector.
- 9)Prior to or in conjunction with the submittal of the Form 6 Subsequent Report of Abandonment, all well production records shall be brought up to date. This includes any periods that the well was shut in or temporary abandoned, as production must be reported from spud to plug even if the well's production is zero.
- 10)See plugging changes above.

Attachment Check List

Att Doc Num	Name
400301297	FORM 6 INTENT SUBMITTED
400301300	WELLBORE DIAGRAM
400301301	PROPOSED PLUGGING PROCEDURE
400301302	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Well completion reports 4/06/1993 & 8/16/1994.	7/3/2012 8:36:47 AM

Total: 1 comment(s)