

PLANNING BMP'S

- Maximize the utility of surface facilities by developing multiple wells from a single pad (directional drilling), and by co-locating multipurpose facilities (for example, well pads and compressors) to avoid unnecessary habitat fragmentation and disturbance of additional geographic areas.
- Minimize newly planned activities and operations within 300 feet of the ordinary high water mark of any reservoir, lake, wetland, or natural perennial or seasonally flowing stream or river.
- Locate roads outside of drainages where possible and outside of riparian habitat.
- Avoid constructing any road segment in the channel of an intermittent or perennial stream
- Minimize the number, length, and footprint of oil and gas development roads
- Use existing roads where possible
- Combine utility infrastructure (gas, electric, and water) planning with roadway planning to avoid separate utility corridors
- Combine and share roads to minimize habitat fragmentation
- Where possible, consolidate pipeline and existing roadways, or roadways that are planned for development
- Place roads to avoid obstructions to migratory routes for wildlife, and to avoid displacement of wildlife from public to private lands.
- Maximize the use of directional drilling to minimize habitat loss/fragmentation
- Maximize use of remote telemetry for well monitoring to minimize traffic
- Restrict oil and gas activities as practical during critical seasonal periods

PRODUCTION/RECLAMATION BMP'S

- Utilize staked soil retention blankets for erosion control and reclamation of large surface areas with 1.5:1 or steeper slopes. Avoid use of plastic blanket materials.
- Remove well pad and road surface materials that are incompatible with post-production land use and re-vegetation requirements
- Use only certified weed-free native seed in seed mixes, except for non-native plants that benefit wildlife
- Williams will use certified, weed free grass hay, straw, hay or other mulch materials used for the reseeding and reclamation of disturbed areas.
- Install exclusionary devices to prevent bird and other wildlife access to equipment stacks, vents and openings.
- Reduce visits to well-sites through remote monitoring (i.e. SCADA) and the use of multi-function contractors.