

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:
400361115

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT
 Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required, Name: PRECUP, JIM Tel: (303) 726-3822
COGCC contact: Email: james.precup@state.co.us

API Number 05-123-08468-00
 Well Name: GLADYS JACCARDI GAS UNIT Well Number: 1
 Location: QtrQtr: NESW Section: 4 Township: 2N Range: 65W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.166829 Longitude: -104.668940
 GPS Data:
 Date of Measurement: 08/15/2006 PDOP Reading: 2.8 GPS Instrument Operator's Name: Chris Fisher
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other See Below
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: Well does not have adequate cement covering the Niobrara formation. Well needs to be abandoned and necessary cement needs to be placed prior to offset horizontal stimulation. CBL to be run prior to cement jobs.

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
J SAND	JSND	7638	7676			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	28	237	200	237	10	VISU
1ST	7+7/8	4+1/2	11.6	7,792	200	7,792	7,022	CALC
		4+1/2	Stage Tool	711	300	711	300	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7600 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 720 ft. to 0 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 7000 ft. with 175 sacks. Leave at least 100 ft. in casing 6600 CICR Depth
 Perforate and squeeze at 4600 ft. with 375 sacks. Leave at least 100 ft. in casing 4130 CICR Depth
 Perforate and squeeze at 870 ft. with 100 sacks. Leave at least 100 ft. in casing 750 CICR Depth
(Cast Iron Cement Retainer Depth)

Set 50 sacks half in. half out surface casing from 287 ft. to 187 ft. Plug Tagged:
 Set 50 sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT
 Title: SR. REGULATORY ANALYST Date: _____ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

Attachment Check List

Att Doc Num	Name
400361120	WELLBORE DIAGRAM
400361121	WELLBORE DIAGRAM
400361122	PROPOSED PLUGGING PROCEDURE

Total Attach: 3 Files

General Comments

User Group	Comment	Comment Date

Total: 0 comment(s)