

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400373023

Date Received:

01/22/2013

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: CHERYL LIGHT

Name of Operator: KERR-MCGEE OIL &amp; GAS ONSHORE LP

Phone: (720) 929-6461

Address: P O BOX 173779

Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217-

Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required, Name: HICKEY, MIKE Tel: (970) 302-1024

COGCC contact: Email: mike.hickey@state.co.us

API Number 05-123-08164-00

Well Name: UPRR 22 PAN AM GAS UNIT O

Well Number: 1

Location: QtrQtr: SWNE Section: 29 Township: 3N Range: 66W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.198540 Longitude: -104.797520

GPS Data:

Date of Measurement: 07/29/2008 PDOP Reading: 2.8 GPS Instrument Operator's Name: Cody Mattson

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☒ Other Not economical to safety prep for a near by horizontal fracCasing to be pulled: ☒ Yes ☐ No Estimated Depth: 875Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7811	7864			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	675	450	675	0	CALC
1ST	7+7/8	4+1/2	10.5	7,977	200	7,980	6,874	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7751 with 2 sacks cmt on top. CIPB #2: Depth 150 with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 150 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 6850 ft. with 100 sacks. Leave at least 100 ft. in casing 6790 CICR Depth

Perforate and squeeze at 5293 ft. with 700 sacks. Leave at least 100 ft. in casing 4152 CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 300 sacks half in. half out surface casing from 925 ft. to 150 ft. Plug Tagged: ☐

Set 50 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST Date: 1/22/2013 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HOLLINSHEAD, RYAN Date: 1/24/2013

### CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 7/23/2013

- 1) Provide 48-hour notice of MIRU to Mike Hickey at (970) 302-1024.
- 2) No CBL on file. Run CBL to verify the top of primary cement. Submit a copy of the CBL with the Subsequent Report of Abandonment.
- 3) Provide an "As Plugged" wellbore diagram identifying the specific plugging completed.
- 4) If unable to pull casing, contact COGCC for plugging modifications.
- 5) Properly abandon flowlines as per Rule 1103.

### **Attachment Check List**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>
400373023	FORM 6 INTENT SUBMITTED
400373027	PROPOSED PLUGGING PROCEDURE
400373028	WELLBORE DIAGRAM
400373029	WELLBORE DIAGRAM

Total Attach: 4 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
Permit	Well Completion report dated 02/17/1975.	1/23/2013 9:25:40 AM

Total: 1 comment(s)