

- Move the 35N BHL to 1650' FWL (inside current spacing unit)
- Change the 35N to a CODELL well = 35C
- Move the 14C BHL to 2110' FWL (inside current spacing unit)
- Change the 14C to a NIO well = 14N

35N 14C

35N 14C

35C 14N

35C 14N

