

Lucas School 33-9

County: Weld
api# 0512319315
Field: Wattenberg

Well Notes:

- Step 1.) Contact landowner 24 hours prior to commencing work on this well.
- 2.) MIRU pulling unit
- 3.) ND Wellhead, NU BOP
- 4.) TOOH w/ 1-1/2" Tubing
- 5.) TIH w/ 1-1/2" tubing and Bit and Scraper
- 6.) MU & TIH w/ 3-1/2" (9.3#) retrievable bridge plug (RBP)
- 7.) Set RBP 50' above Codell Perforations (7256')
- 8.) TOOH w/ 1-1/2" Tubing
- 9.) RU rig pump & pressure test csg to 500psi for 15 minutes;
- 10.) Chart record & report test result to Denver & State
- 11.) ND BOP, NU Tree & Flowline
- 12.) Turn in final MIT sundry to State