

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400503338

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Jenifer Hakkarinen

Name of Operator: PDC ENERGY INC

Phone: (303) 8605800

Address: 1775 SHERMAN STREET - STE 3000

Fax: (303) 8605838

City: DENVER State: CO Zip: 80203

Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required,

Name: PRECUP, JIM

Tel: (303) 726-3822

COGCC contact:

Email: james.precup@state.co.us

API Number 05-123-11879-00

Well Name: MAPELLI

Well Number: 3

Location: QtrQtr: NESW Section: 20 Township: 7N Range: 65W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 55714

Field Name: EATON

Field Number: 19350

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.558622

Longitude: -104.689353

GPS Data:

Date of Measurement: 02/04/2010

PDOP Reading: 1.5

GPS Instrument Operator's Name: Robert Girillego

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☒ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 6110

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
CODELL	CODL	7320	7330			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	13+3/4	8+5/8	24	310	300	310	0	
1ST	7	4+1/2	11.6	7,393	170	7,393	0	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7270 with 0 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 6110 ft. to 6010 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set 200 sks cmt from 3000 ft. to 4000 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 200 sacks half in. half out surface casing from 500 ft. to 0 ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Plugging Procedure
Codell
Existing Perforations:
Codell: 7320'-7330'
PBSD: 7385'
8 5/8" 24# @ 310' W/ 300 sks cmt.
4 1/2" 11.6# @ 7393' w/ 170 sks cmt
Procedure:
1)MIRU wireline
2)RIH w/CIBP set @ 7270'
3)RIH w/dump bailer and dump 2 sx cement on top of CIBP
4)RIH w/casing cutter, cut & pull casing @ ~6110'
5)TIH set 50 sack plug @ casing stub (6110')
6)TIH to tag stub plug
7)Set 200 sackl plug to cover Parkman/Sussex (~3000'-4000')
7)TOH and set 200 sack cement plug 500' to surface
8)Set 10 sx @ top of surface
9)Cut casing and weld on cap

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jenifer Hakkarinen

Title: Regulatory Tech Date: _____ Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved. _____

COGCC Approved:

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

--	--

Attachment Check List

Att Doc Num

Name

400503347	WELLBORE DIAGRAM
400503348	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

--	--	--

Total: 0 comment(s)