

SUMMARY: THE VERTICAL AND FIRST LATERAL WILL BE ONE CONTINUOUS WELL BORE. COME BACK TO SET WHIPSTOCK AT KICK OFF POINT FOR UPPER LATERAL TO TMD. THEN SET UNCEMENTED LINER IN UPPER LATERAL. RUN TUBING STRING TO A POINT OF APPROX. 50-60° INCLINATION ON MAIN LATERAL AND PUMP TOGETHER.

CAMPAD

1 SURFACE CASING 9 5/8"
SETTING DEPTH @ 500
CEMENT 0-250

INTERMEDIATE CASING 7"
SETTING DEPTH @ 2610
CEMENT 0-2610

KICK OFF POINT (TMD @ ~2600)

2660 1 INTERMEDIATE CASING 7"
SETTING DEPTH 2610
CEMENT 0-2610

JENNIE ROSE 33-7-3 #3BTC (FOR TOP COAL)
JENNIE ROSE 33-7-3 #3BBC (FOR BASE COAL)

INCLUDE THESE NAMES IN COMMENT SECTION OF APP.

2860 FRUITLAND COAL
TMD @ 5881.25

2985 TOP BASAL COAL TZ
TMD @ 6007.24

BASE BASAL COAL TZ

PICTURED CLIFFS

0 250 500 750 1750 3000 3250