

Red River Ranch
Las Animas County

PROPOSED PLUGGING PROCEDURE RRR 15-3

LOCATE, TEST OR REPLACE AS NEEDED ALL DEADMAN ANCHORS.

MIRU ECWS.

MIRU FLOWBACK TANK AND PLUMB INTO BACKSIDE.

BLEED OF CASING AND TBG INTO TANK.

POOH WITH RODS AND LAY DOWN

POOH WITH TBG AND STAND BACK IN DERRICK.

TIH WITH 5-1/2 CASING SCRAPER TO TOP PERF

POOH WITH TBG AND SCRAPER. TIH WITH 5-1/2 CIBP' ON TUBING AND SET @ 750'. PU AND LOAD HOLE. POOH WITH TBG AND REMOVE SETTING TOOL. RIH WITH DUMP BAILER LOADED WITH 2 SKS OF CLASS G CEMENT AND SPOT ON TOP OF CIBP.

POOH WITH BAILER.

TIH WITH CIBP TO 258'+. SET CIBP AND STING OUT. RU CEMENTERS, PUMP 15 SKS (2.5 BBLs) OF CLASS G CEMENT DOWN TBG. PUMP DISPLACEMENT LEAVING .25 BBLs IN TUBING. PU 2 JTS SLOWLY TO SPOT CEMENT. POOH WITH TBG

TIH W/TBG TO 50' RU CEMENTERS AND PUMP 5 SKS APPX. 1 BBL OF CEMENT TO BRING CEMENT TO SURFACE.

CUT OFF WELLHEAD TIH WITH 1" TBG DOWN TO APPX 100'. RU CEMENTERS AND TOP OF ANNULUS WITH CEMENT TO SURFACE. POOH WITH 1" TBG AND TOP OFF. RUN 1" OUTSIDE SURFACE CASING TO 100+-. TOP OFF TO SURFACE. POOH WITH 1"

RDMO ECWS DIG BELL HOLE AROUND WELLHEAD AND CONTACT TOPAR WELDING. CUT CASING OFF 4' BELOW GROUND LEVEL AND WELD ON PLATE ACCORDING TO COGCC RULES. TURN OVER TO RECLAMATION.