

Red River Ranch
Las Animas County

PROPOSED PLUGGING PROCEDURE RRR 13-6

LOCATE, TEST OR REPLACE AS NEEDED ALL DEADMAN ANCHORS.

MIRU ECWS.

MIRU FLOWBACK TANK AND PLUMB INTO BACKSIDE.

BLEED OF CASING AND TBG INTO TANK.

POOH WITH RODS AND LAY DOWN

POOH WITH TBG AND STAND BACK IN DERRICK.

TIH WITH 5-1/2 CASING SCRAPER TO TOP PERF

POOH WITH TBG AND SCRAPER. TIH WITH 5-1/2 CIBP' ON TUBING AND SET @ 654'. PU AND LOAD HOLE. POOH WITH TBG AND REMOVE SETTING TOOL. RIH WITH DUMP BAILER LOADED WITH 2 SKS OF CLASS G CEMENT AND SPOT ON TOP OF CIBP.

POOH WITH BAILER.

TIH WITH CIBP #2 AND SET AT 255'-±. STING OUT. RU CEMENTERS, PUMP 15 SKS (2.5 BBLS) OF CLASS G CEMENT DOWN TBG. PUMP DISPLACEMENT. PU 2 JTS SLOWLY TO SPOT CEMENT. POOH WITH TBG STANDING BACK.

TIH W/TBG TO 50' RU CEMENTERS AND PUMP 5 SKS APPX 1 BBL OF CEMENT TO BRING CEMENT TO SURFACE. CUT OFF WELLHEAD VERIFY TOC IS AT SURFACE.

RDMO ECWS DIG BELL HOLE AROUND WELLHEAD AND CONTACT TOPAR WELDING. CUT CASING OFF 4' BELOW GROUND LEVEL AND WELD ON PLATE ACCORDING TO COGCC RULES. TURN OVER TO RECLAMATION.