

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400571035			
Date Received: 03/13/2014			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Jonathan Pomerantz
 Name of Operator: NOBLE ENERGY INC Phone: (970) 304-5222
 Address: 1625 BROADWAY STE 2200 Fax: (970) 304-5099
 City: DENVER State: CO Zip: 80202 Email: JPomerantz@nobleenergyinc.com

For "Intent" 24 hour notice required, Name: Gomez, Jason Tel: (970) 573-1277
COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-21942-00 Well Number: 13-32
 Well Name: DINNER
 Location: QtrQtr: NWSW Section: 13 Township: 6N Range: 65W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.484337 Longitude: -104.618652
 GPS Data:
 Date of Measurement: 02/18/2007 PDOP Reading: 5.9 GPS Instrument Operator's Name: David Gipson
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 2500
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7023	7038			
NIOBRARA	6709	6865			
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	396	270	396	0	VISU
1ST	7+7/8	4+1/2	11.6	7,128	140	7,128	6,190	CBL
S.C. 1.1	7+7/8	4+1/2	11.6	6,190	484	6,190	3,080	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6650 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 75 sks cmt from 3800 ft. to 3000 ft. Plug Type: CASING Plug Tagged:
 Set 100 sks cmt from 2550 ft. to 2350 ft. Plug Type: STUB PLUG Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 175 sacks half in. half out surface casing from 500 ft. to 0 ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Marilyn Tucker
 Title: Engineering Tech Date: 3/13/2014 Email: Mtucker@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURN, DIANA Date: 3/28/2014

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 9/27/2014

COA Type	Description
	1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) For 500' plug: pump plug and displace. If surface casing plug not circulated to surface then tag plug – must be 350' or shallower and provide 10 sx plug at the surface. Leave at least 100' cement in the casing for each plug. 3) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400571035	FORM 6 INTENT SUBMITTED
400571061	PROPOSED PLUGGING PROCEDURE
400571063	WELLBORE DIAGRAM
400571064	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	file not yet reviewed	3/28/2014 10:21:32 AM

Total: 1 comment(s)