

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

Document Number:
400573718

Date Received:
03/18/2014

OGCC Operator Number: 100322 Contact Name: EILEEN ROBERTS

Name of Operator: NOBLE ENERGY INC Phone: (303) 228-4330

Address: 1625 BROADWAY STE 2200 Fax: (303) 228-4286

City: DENVER State: CO Zip: 80202 Email: eroberts@nobleenergyinc.com

For "Intent" 24 hour notice required, Name: Gomez, Jason Tel: (970) 573-1277

COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-05206-00

Well Name: SANDER Well Number: 1

Location: QtrQtr: SWSW Section: 30 Township: 6N Range: 64W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.451335 Longitude: -104.599597

GPS Data:
Date of Measurement: _____ PDOP Reading: _____ GPS Instrument Operator's Name: _____

Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems

Other Re-well, set balanced plug, PA well w/new cement

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: See attached procedure of Re-entry and new PA.

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	10+3/4	24.00	366	35	366	0	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

PROCEDURE:

- 1) Survey and locate abandoned well, mark with stake
- 2) Excavate to expose top of surface casing
- 3) Weld 2" collar to top of 8 5/8" surface casing cap. Make up to collar, pneumatic drill with non-sparking bit. Drill out cap venting possible trapped gas.
- 4) Once verified that no gas exists beneath top of surface casing plate, cut off surface casing below plate with torch, dress up smooth.
- 5) Butt weld 10 3/4" casing to dressed cut, bringing threaded end of casing to ground level.
- 6) Make up to 10 3/4" casing, one 10 3/4" collar and 10 3/4" starter well head
- 7) NU flange adaptor and 5k BOP, test BOP.
- 8) NU and RIH with 6 7/8" cone bit, PU 2 7/8" drill collar, 2 7/8" 8.7# tubing, and TIW valve
- 9) Drill out first cement plug inside surface casing, roll hole clean. Verify top of next cement plug inside of surface casing by tagging.
- 10) If unable to verify isolation of surface casing with tag of cement plug, set RBP inside surface casing
- 11) Once isolation of surface casing is established, either with tagging of surface plug or setting of RBP, pressure test surface casing to 200psi
- 12) After pressure test of surface casing, retrieve RBP or continue drill out of cement plug under surface casing shoe.
- 13) Assume pressure under surface casing shoe, roll hole with kill fluid until well dead, or blow down.
- 14) Continue RIH, cleaning out with drilling mud or water to 3000'
- 15) TOOH with cone bit, drill collars, and 2 7/8" tubing.
- 16) PU and RIH with mule shoe and 2 7/8" tubing to 3000'
- 17) RU cement crew and pump a balanced plug of 100 sks 15.8 ppg Class G "neat" cement @ 3000'
- 18) POOH to 458' (150' below Fox Hills Base @ 308')
- 19) RU cement crew and pump 270 sxs of 15.8ppg Class G "neat" cement bring cement to surface
- 20) POOH with 2 7/8" tubing. Wait 4 hrs, and tag TOC. If cement has fallen, top off back to surface
- 21) Let cement set over night, verify cement has not settled and is still at surface. RDMO
- 22) Excavate around wellhead to 8' below grade, cut off 8 5/8" casing, weld on cap
- 23) Backfill hole and reclaim surface to original conditions

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Eileen Roberts
Title: Analyst I Date: 3/18/2014 Email: eroberts@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 4/2/2014

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 10/1/2014

COA Type	Description
	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) Properly abandon flowlines as per Rule 1103. Once properly abandoned file electronic form 42. 3) Operator must provide well location GPS coordinates on Subsequent Report of Abandonment in accordance with COGCC As-Built Location Policy and Rule 215.

Attachment Check List

Att Doc Num	Name
400573718	FORM 6 INTENT SUBMITTED
400573782	WELLBORE DIAGRAM
400573783	OTHER
400573785	PROPOSED PLUGGING PROCEDURE
400573786	WELLBORE DIAGRAM
400573787	OTHER

Total Attach: 6 Files

General Comments

User Group	Comment	Comment Date
Permit	1) As built GPS coordinates will be provided on the form 6, SRA. 2) Operator will submit a Form 42 - Offset Mitigation Completed for the re-plugged well, referencing the API Number of the proposed horizontal well. 3) Operator will submit a Form 4 to report date Final Reclamation will commence. Final reclamation should begin as soon as practicable.	3/18/2014 3:58:18 PM
Permit	Field reclamation inspection from 1997 in well file.	3/18/2014 3:57:12 PM

Total: 2 comment(s)