

FORM  
6Rev  
12/05State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400640309

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: REBECCA HEIM

Name of Operator: KERR MCGEE OIL &amp; GAS ONSHORE LP

Phone: (720) 929-6361

Address: P O BOX 173779

Fax: (720) 929-7361

City: DENVER State: CO Zip: 80217-

Email: REBECCA.HEIM@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: \_\_\_\_\_

Tel: \_\_\_\_\_

COGCC contact:

Email: \_\_\_\_\_

API Number 05-123-08160-00

Well Name: UPRR 22 PAN AM GAS UNIT H

Well Number: 1

Location: QtrQtr: SWNE Section: 13 Township: 3N Range: 66W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.227990

Longitude: -104.721630

GPS Data:

Date of Measurement: 09/09/2008

PDOP Reading: 2.2

GPS Instrument Operator's Name: Cody Mattson

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☐ Other \_\_\_\_\_Casing to be pulled: ☐ Yes ☐ No Estimated Depth: \_\_\_\_\_Fish in Hole: ☐ Yes ☐ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7909	7962			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+3/4	8+5/8	24	640	425	640	0	VISU
1ST	7+7/8	4+1/2	10.5/11.6	8,073	200	8,073	7,385	CBL
			Stage Tool	665	200	665	350	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7830 with 2 sacks cmt on top. CIBP #2: Depth 145 with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 7360 ft. with 310 sacks. Leave at least 100 ft. in casing 6765 CICR Depth

Perforate and squeeze at 4970 ft. with 700 sacks. Leave at least 100 ft. in casing 4370 CICR Depth

Perforate and squeeze at 1420 ft. with 525 sacks. Leave at least 100 ft. in casing 760 CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing

Plugging Date: 06/27/2014

\*Wireline Contractor: WARRIOR

\*Cementing Contractor: SANJEL

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

\*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: REBECCA HEIM

Title: SR. REGULATORY ANALYST

Date: \_\_\_\_\_

Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

\_\_\_\_\_

### Attachment Check List

Att Doc Num

Name

400640313	OPERATIONS SUMMARY
400640314	CEMENT JOB SUMMARY
400640317	WELLBORE DIAGRAM
400640318	GYRO SURVEY
400640319	WIRELINE JOB SUMMARY

Total Attach: 5 Files

### General Comments

User Group

Comment

Comment Date

--	--	--

Total: 0 comment(s)