

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

Document Number:  
 400643210  
 Date Received:

OGCC Operator Number: 47120 Contact Name: REBECCA HEIM  
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6361  
 Address: P O BOX 173779 Fax: (720) 929-7361  
 City: DENVER State: CO Zip: 80217- Email: REBECCA.HEIM@ANADARKO.COM

**For "Intent" 24 hour notice required,** Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 COGCC contact: Email: \_\_\_\_\_

API Number 05-123-07803-00  
 Well Name: BRETHAWER, JAKE B Well Number: 1  
 Location: QtrQtr: SWNE Section: 14 Township: 3N Range: 66W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.228376 Longitude: -104.740859  
 GPS Data:  
 Date of Measurement: 07/11/2014 PDOP Reading: 6.0 GPS Instrument Operator's Name: RH  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7849	7901	12/12/1982	CEMENT	4348
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	537	400	537	0	VISU
1ST	7+7/8	4+1/2	10.5	8,000	200	8,000	7,475	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 100 with \_\_\_\_\_ sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 200 sks cmt from 3950 ft. to 3500 ft. Plug Type: CASING Plug Tagged:   
Set 600 sks cmt from 1330 ft. to 114 ft. Plug Type: CASING Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set 57 sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 07/09/2014  
\*Wireline Contractor: PIONEER \*Cementing Contractor: SANJEL  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

"As Built" submitted via spreadsheet by Noble so date, PDOP and Operator Name are not available; however, Lat/Long are correct. This well was originally abandoned in 1982 with production casing cut off at 4350' (parted). Well is to be re-entered to add cement plugs at 4040' to 3840' and Fox Hills coverage from 780' to 337'. A tubing fish was reported at approximately 4350' (depth of the parted casing) in 1982.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: REBECCA HEIM  
Title: SR. REGULATORY ANALYST Date: \_\_\_\_\_ Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400643211	OPERATIONS SUMMARY
400643212	GYRO SURVEY
400643213	WELLBORE DIAGRAM
400643214	WELLBORE DIAGRAM
400643215	CEMENT JOB SUMMARY

Total Attach: 5 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)