

FORM  
6Rev  
12/05State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400645379

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: REBECCA HEIM

Name of Operator: KERR MCGEE OIL &amp; GAS ONSHORE LP

Phone: (720) 929-6361

Address: P O BOX 173779

Fax: (720) 929-7361

City: DENVER State: CO Zip: 80217-

Email: REBECCA.HEIM@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: \_\_\_\_\_

Tel: \_\_\_\_\_

COGCC contact:

Email: \_\_\_\_\_

API Number 05-123-21105-00

Well Name: HLADKY

Well Number: 12-21A

Location: QtrQtr: NWSW Section: 21 Township: 2N Range: 66W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.121950

Longitude: -104.789750

GPS Data:

Date of Measurement: 05/01/2008

PDOP Reading: 1.9

GPS Instrument Operator's Name: Cody Mattson

Reason for Abandonment: ☐ Dry☐ Production for Sub-economic☐ Mechanical Problems☐ Other \_\_\_\_\_Casing to be pulled: ☐ Yes☐ No

Estimated Depth: \_\_\_\_\_

Fish in Hole: ☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7470	7484	06/25/2014		
J SAND	7844	7894	06/25/2014		
NIOBRARA	7193	7283	06/27/2014		

Total: 3 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	932	560	932	0	VISU
1ST	7+7/8	4+1/2	11.6	8,011	197	8,011	6,495	CBL
			Stage Tool	4,902	295	4,902	4,099	CBL

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7760 with 2 sacks cmt on top. CIBP #2: Depth 7100 with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth 7082 with 30 sacks cmt on top. CIBP #4: Depth 80 with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 4820 ft. to 4120 ft. Plug Type: CASING Plug Tagged: ☐  
Set 270 sks cmt from 1602 ft. to 600 ft. Plug Type: STUB PLUG Plug Tagged: ☒  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☒  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 32 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 07/10/2014

\*Wireline Contractor: PIONEER

\*Cementing Contractor: SANJEL

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

\*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: REBECCA HEIM

Title: SR. REGULATORY ANALYST

Date: \_\_\_\_\_

Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

\_\_\_\_\_

### Attachment Check List

**Att Doc Num****Name**

400645397	OPERATIONS SUMMARY
400645398	WELLBORE DIAGRAM
400645399	WIRELINE JOB SUMMARY
400645400	CEMENT JOB SUMMARY
400645492	CEMENT BOND LOG
400645593	CEMENT BOND LOG

Total Attach: 6 Files

### General Comments

**User Group****Comment****Comment Date**

--	--	--

Total: 0 comment(s)