

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400653264			
Date Received: 07/30/2014			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name Cheryl Light
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment
Checklist

OP OGCC

API Number : 05- 123 29025 00 OGCC Facility ID Number: 298298
 Well/Facility Name: STATE Well/Facility Number: 22-16
 Location QtrQtr: NESW Section: 16 Township: 1N Range: 68W Meridian: 6
 County: WELD Field Name: WATTENBERG
 Federal, Indian or State Lease Number: 70/8570-S

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location * ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
 Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr NESW Sec 16

New **Surface** Location **To** QtrQtr _____ Sec _____

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec 16

New **Top of Productive Zone** Location **To** Sec _____

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec 16 Twp 1N

New **Bottomhole** Location Sec _____ Twp _____

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,
 property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

FNL/FSL		FEL/FWL	
1983	FSL	1886	FWL
Twp <u>1N</u>	Range <u>68W</u>	Meridian <u>6</u>	
Twp _____	Range _____	Meridian _____	
2552	FSL	1304	FWL
Twp <u>1N</u>	Range <u>68W</u>		
Twp _____	Range _____		
2552	FSL	1304	FWL
			**

** attach deviated drilling plan

CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

OTHER CHANGES

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name STATE Number 22-16 Effective Date: _____

To: Name _____ Number _____

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number _____ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number _____ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number _____ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: _____

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: _____

RECLAMATION**INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately _____

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

Field inspection will be conducted to document Rule 1003.e. compliance

FINAL RECLAMATION

☐ Final Reclamation will commence approximately _____

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

Field inspection will be conducted to document Rule 1004.c. compliance

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

☐ SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 08/04/2014

☐ REPORT OF WORK DONE Date Work Completed _____

- | | | |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare | <input type="checkbox"/> E&P Waste Mangement Plan |
| <input type="checkbox"/> Change Drilling Plan | <input checked="" type="checkbox"/> Repair Well | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. | |
| <input type="checkbox"/> Other _____ | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases | |

COMMENTS:

BRADENHEAD - THIS FORM 4 REPLACES THE FORM 4 FILED IN AUGUST 2013. NEW CEMENTING PROCEDURES ARE ATTACHED.

State 22-16 -- Revised Bradenhead Procedure

1 Call Foreman or Lead Operator at least 24 hr prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.

2 MIRU Slick line. Fish plunger if necessary and tag for PBTD (should be at 8222').

3 This well needs a gyro survey before any work is completed.

4 Prepare location for base beam rig.

5 Spot 12 jts of 2-3/8" 4.7# J-55 8RD EUE tbgr.

6 Spot 50 jts of 1-1/4" 2.33# J-55 10rd IJ tbgr.

7 Check wellhead for 5,000 psi rating. If wellhead is not rated to 5,000 psi, install one that is prior to completing job.

8 MIRU WO rig. Kill well with fresh water with biocide. ND wellhead, NU BOPs.

9 Run two 2" lines from starting head to return tanks

10 PU 8-10' landing joint with TIW safety valve on top and screw into the tbgr hanger. Back out the lock down pins and pull up on the tbgr string to break any possible sand bridges. Do not exceed 80% of tubing tensile strength, or 57,384-lb.

11 Unseat tbgr hanger and LD tbgr hanger and landing joint. Install rubber wiper in stripping head.

12 MIRU EMI equipment. TOOHe with 2-3/8" tbgr. EMI tbgr while TOOHe. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Keep yellow and blue band tubing. Note joint number and depth of tubing leak(s) on production equipment failure report in OpenWells. Clearly mark all junk (red band) tubing sent to yard.

13 This well already has an RBP set at 7519'.

14 Pressure test RBP to 1,000 psi for 15 minutes. (Pressure test to make sure plug is set correctly)

15 ND bop, ND tubing head. Un land 4-1/2" csg string. NU double entry flange, NU BOP.

16 PU and TIH with 50 jts of 1-1/4" 2.33# J-55 10rd IJ tbgr outside 4 1/2" csg to +/- 1500'. Circulate while TIH to condition hole.

17 MIRU Cement company.

18 Commence pumping cement job at pump rate of consisting 5 bbl fresh water, 20 bbl sodium meta silicate and 5 bbl fresh water; 39 bbl (165 sx) of Type III and 1/4 lb/sk cello-flake mixed at 14.8 ppg and 1.33 cuft/sk blended for a 3 hr pump time (Cement from 1500' to 794').

19 TOOHe with 27 jts of 1-1/4" tbgr and circulate 2x tubing volume or until cement cleans up. TOOHe remaining 1-1/4" tbgr and LD all 1-1/4" tbgr.

20 Break lines and clean up with fresh water. RMDO cement company.

21 ND bop, ND dual entry flange. NU 2-3/8" tbgr head and BOP.

22 Leave well shut in for 24 hours.

23 Circulate gas out of hole with fresh water with biocide.

24 MIRU wire line and run CCL/CBL/VDL from 1600' to 0'. If cement is not above 794', contact engineering for further instructions. RDMO wire line.

25 Pressure test csg to 5,000 psig for 15 minutes. If pressure does not hold, contact engineering for further support.

26 TIH with 2 3/8" tbgr and retrieving head and tag sand above RBP. Circulate sand off RBP. Latch onto RBP at +/- 7519' and release RBP. TOOHe standing back all 2 3/8" tbgr and LD RBP.

27 TIH with 2-3/8" XN SN and 2-3/8" 4.7# J55 EUE tbgr. Land tbgr @ +/- 7980' (1 jt above top Codell perf). Broach tbgr to XN nipple.

28 ND BOP, Install 7 1/16" x 5,000 psi tubing head adaptor with new 5,000 psi master valve threaded 2 3/8" connection. Make sure all wellhead valves are rated to 5,000 psi.

29 NU master valve and hydrotest tubing head to 5,000 psi for 15 minutes.

30 RMDO WO rig.

31 Clean location and swab well back to production. Notify field foreman/field coordinator of finished work and turn well back over to production team.

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million)

Date of Measurement or Sample Collection _____

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

Best Management Practices		
No	BMP/COA Type	Description

Operator Comments:

--

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light
Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: 7/30/2014

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 8/1/2014

CONDITIONS OF APPROVAL, IF ANY:**COA Type****Description**

------	------

General Comments**User Group****Comment****Comment Date**

Engineer	1) The additional cement referenced shall be placed as indicated and comply with Rule 317.i. The placed cement shall be verified with a CBL and documented with a Form 5 Drilling Completion Report. 2) Please submit gyro survey data with Form 5 Drilling Completion Report.	3/1/2014 8:53:45 AM
----------	---	---------------------

Total: 1 comment(s)

Attachment Check List**Att Doc Num****Name**

400653264	FORM 4 SUBMITTED
400653267	OTHER
400653268	WELLBORE DIAGRAM

Total Attach: 3 Files