

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400657964

Date Received:

08/06/2014

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Jonathan Pomerantz

Name of Operator: NOBLE ENERGY INC

Phone: (970) 304-5222

Address: 1625 BROADWAY STE 2200

Fax: (970) 304-5099

City: DENVER State: CO Zip: 80202

Email: JPomerantz@nobleenergyinc.com

For "Intent" 24 hour notice required,

Name: Rickard, Jeffrey

Tel: (303) 8942100

COGCC contact:

Email: jeffrey.rickard@state.co.us

API Number 05-123-12526-00

Well Name: MUIRHEAD

Well Number: 1-2

Location: QtrQtr: NESW Section: 1 Township: 4N Range: 65W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 68068

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.339108

Longitude: -104.613358

GPS Data:

Date of Measurement: 06/13/2006

PDOP Reading: 5.6

GPS Instrument Operator's Name: David Gipson

Reason for Abandonment: ☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 4600

Fish in Hole: ☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7064	7078			
NIOBRARA	6772	6964			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	305	250	305	0	VISU
1ST	7+7/8	4+1/2	11.6	7,173	155	7,173	6,372	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6722 with 2 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 125 sks cmt from 4650 ft. to 4450 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set 50 sks cmt from 2500 ft. to 2400 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 225 sacks half in. half out surface casing from 560 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Marilyn Tucker

Title: engineering tech Date: 8/6/2014 Email: mtucker@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 8/14/2014

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 2/13/2015

COA Type

Description

COA Type	Description

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400657964	FORM 6 INTENT SUBMITTED
400657978	WELLBORE DIAGRAM
400657979	WELLBORE DIAGRAM
400657980	PROPOSED PLUGGING PROCEDURE

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Note changes to plugging procedure: 1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) For 4650' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 4450' or shallower. If circulation is maintained no need to tag plug. 3) For 560' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 205' or shallower. Provide 10 sx plug at the surface. Leave at least 100' cement in the casing for each plug. 4) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.	8/14/2014 1:13:56 PM
Permit	Well Completion Report dated 10/03/1985.	8/12/2014 2:16:55 PM

Total: 2 comment(s)