

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400678807			
Date Received: 09/03/2014			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name Cheryl Light
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment
Checklist

OP OGCC

API Number : 05- 123 26795 00 OGCC Facility ID Number: 296475
 Well/Facility Name: EVERIST Well/Facility Number: 23-10
 Location QtrQtr: SWSE Section: 10 Township: 2N Range: 68W Meridian: 6
 County: WELD Field Name: WATTENBERG
 Federal, Indian or State Lease Number: _____

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

- Change of Location * As-Built GPS Location Report As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
 Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr SWSE Sec 10

New **Surface** Location **To** QtrQtr _____ Sec _____

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec 10

New **Top of Productive Zone** Location **To** Sec _____

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec 10 Twp 2N Range 68W

New **Bottomhole** Location Sec _____ Twp _____ Range _____

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,
 property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

FNL/FSL		FEL/FWL	
<u>1169</u>	<u>FSL</u>	<u>1475</u>	<u>FEL</u>
_____	_____	_____	_____
Twp <u>2N</u>	Range <u>68W</u>	Meridian <u>6</u>	
Twp _____	Range _____	Meridian _____	
<u>1375</u>	<u>FSL</u>	<u>2594</u>	<u>FWL</u>
_____	_____	_____	_____
Twp <u>2N</u>	Range <u>68W</u>		
Twp _____	Range _____		
<u>1375</u>	<u>FSL</u>	<u>2594</u>	<u>FWL</u>
_____	_____	_____	_____

**

**

** attach deviated drilling plan

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

NOTICE OF INTENT Approximate Start Date 09/17/2014

REPORT OF WORK DONE Date Work Completed _____

<input type="checkbox"/> Intent to Recomplete (Form 2 also required)	<input type="checkbox"/> Request to Vent or Flare	<input type="checkbox"/> E&P Waste Mangement Plan
<input type="checkbox"/> Change Drilling Plan	<input checked="" type="checkbox"/> Repair Well	<input type="checkbox"/> Beneficial Reuse of E&P Waste
<input type="checkbox"/> Gross Interval Change	<input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request.	
<input type="checkbox"/> Other _____	<input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases	

COMMENTS:

BRADENHEAD

- 1 GYRO ran on 7/29/08.
- 2 Call Foreman or Lead Operator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.
- 3 MIRU slickline. Fish plunger from lubricator. RIH and pull the bumper spring and standing valve if necessary. RBIH with sinker bars and tag bottom. Report findings. PBMD should be at 7711'. RDMO slickline.
- 4 Prepare location for base beam rig.
- 5 Spot a minimum of 25 jts of 2-3/8", 4.7#, J-55, EUE tbg for replacement and 65 jts 1-1/4", 2.33#/ft, J-55, 10rd IJ for annular cement job.
- 6 MIRU WO rig and auxiliary equipment. Check pressures. Rig up 2" line from the casing head annulus to work tank. Kill well with fresh water. ND tree and adapter flange, NU BOP's.
- 7 PU 8-10' landing joint. TIW valve on top and screw into the tbg hanger. Back out the lock down pins and pull up on tbg string to break any possible sand bridges, unseat landing joint and lay down. Do not exceed 80% of tubing tensile strength, or 57,380-lb. Clean out as necessary to 7711'.
- 8 MIRU EMI equipment. TOOH with 2-3/8" tbg. EMI tbg while TOOH. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Note joint number and depth of tubing leak(s) on production equipment failure report in Open Wells. Clearly mark all junk (red band) tubing sent to yard.
- 9 TIH with 2-3/8" tbg and 4.5" RBP. Set RBP @ +/-7220', (collars are at 7192' and 7235'). Pressure test RBP to 5000 psi. Spot 2sx of sand on top of RBP and TOOH.
- 10 Bleed off pressure. ND BOP's, ND wellhead, Un-land 4 1/2" casing, NU dual entry flange, NU BOP.
- 11 PU 1-1/4" 2.3#/ft J-55 10rd IJ tubing, and TIH outside 4-1/2" casing in open hole to ~2000'. Circulate with the rig pump while TIH to clean up the annulus. Use sweeps as necessary until clean returns are seen. Make sure no pressure is present on braden head before moving on to the next step. If gas is detected, contact engineering to discuss plan moving forward.
- 12 Contact Imperial mud (min of 24hrs. in advance) to bring out 40bbls of 10.0 ppg mud. Pump 40bbls of mud at 2000'. Leave 1-1/4" tbg full of mud to avoid wet trip and PUH to 1600' to displace cement.
- 13 MIRU cement services. Circulate 5 bbls water, 10 bbls mud flush and 5 bbls water. Prepare to cement.
- 14 Mix and pump 220sx (~52.1bbls) of 14.8 ppg (1.33 cuft/sk) Type III w/ 1/4 lb/sk cello-flake. The cement is to be retarded for 80 degrees F and 3 hour pump time. Design is for coverage from ~1600' to ~715'.
- 15 TOOH ~38 joints to ~400' and reverse circulate 2 times the tubing volume of water or until clean returns are seen. TOOH with 1-1/4" tubing.
- 16 RDMO cementing company.
- 17 ND BOP. ND dual entry flange and crossover. Pick up and land 4-1/2" casing in slips. NU new 4-1/2" 5000 psi tubing head with 2-5000 psi valves {use new style flanged well head equipment if available}. NU BOP's to tubing head.
- 18 Leave well shut in for ~36hrs.
- 19 MIRU wireline and run CCL-GR-CBL-VOL from 3400' to surface. If top of cement is below 715' notify Engineering. In addition to normal handling of logs/job summaries, email copies of all cement job logs/job summaries and invoices to rscOJVendors@anadarko.com within 24 hours of the completion of the job.
- 20 RDMO wireline.
- 21 PU and TIH with 2-3/8" tbg and retrieving head. Circulate sand off RBP at @ +/-7220'. TOOH with RBP and SB tbg.
- 22 TIH with 2-3/8" NC, 2-3/8" XN SN and 2-3/8" 4.7# J55 EUE tbg, circulate out fill if necessary to 7711'. Land tbg @ +/- 7538' (1 jt above top Codell perf).
- 23 Broach tubing to seating nipple. NO BOP's, NU master valve and tubing head adaptor. Hydrotest tubing head to 5000 psi for 15 minutes.
- 24 RDMO WO rig.
- 25 Clean location and swab well back to production. Notify Field Foreman/Field Coordinator of finished work and turn well back over to production team.

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million)

Date of Measurement or Sample Collection _____

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

<u>Best Management Practices</u>	
<u>No BMP/COA Type</u>	<u>Description</u>

Operator Comments:

[Empty box for Operator Comments]

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light
Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: 9/3/2014

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 9/15/2014

CONDITIONS OF APPROVAL, IF ANY:

COA Type

Description

	The additional cement referenced shall be placed as indicated and comply with Rule 317.i. The placed cement shall be verified with a CBL and documented with a Form 5 Drilling Completion Report.
--	---

General Comments

User Group

Comment

Comment Date

--	--	--

Total: 0 comment(s)

Attachment Check List

Att Doc Num

Name

400678807	FORM 4 SUBMITTED
400678808	OTHER

Total Attach: 2 Files