

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400711443

Date Received:

10/20/2014

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10110

Contact Name: Sam Bradley

Name of Operator: GREAT WESTERN OPERATING COMPANY LLC

Phone: (970) 286-3426

Address: 1801 BROADWAY #500

Fax:

City: DENVER State: CO Zip: 80202

Email: sbradley@gwogco.com

For "Intent" 24 hour notice required,

Name: Montoya, John

Tel: (970) 3974124

COGCC contact:

Email: john.montoya@state.co.us

API Number 05-123-24440-00

Well Name: SIRIOS

Well Number: 22-1

Location: QtrQtr: SENW Section: 1 Township: 1N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.082140

Longitude: -104.501690

GPS Data:

Date of Measurement: 05/22/2007

PDOP Reading: 3.7

GPS Instrument Operator's Name: HOLLY TRACY

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7424	7442			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	1,009	710	1,009	0	VISU
1ST	7+7/8	4+1/2	11.6	7,589	230	7,589	6,250	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7350 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 1050 ft. to 595 ft. Plug Type: CASING Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 1100 ft. with 120 sacks. Leave at least 100 ft. in casing 1050 CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Please see the attached current & proposed wellbore diagrams. Plugging is designed to set a CIBP and cement above the J-Sand perforations, set a shoe plug, and cut and pull at surface with a surface plug.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Sam Bradley

Title: Petroleum Engineer Date: 10/20/2014 Email: sbradley@gwogco.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 11/14/2014

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 5/13/2015

<u>COA Type</u>	<u>Description</u>
	<p>Note change in plugging procedure:</p> <p>1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU.</p> <p>2) Proposed casing shoe plug does not provide adequate aquifer isolation so switching to perf casing shoe plug.</p> <p>3) For 1100' plug: perforate casing, pump plug and displace, shut-in, WOC 4 hours and tag plug (must be 595' or shallower to isolate Laramie Fox Hills aquifer from shallower Lower Arapahoe aquifer).</p> <p>4) Leave at least 100' cement in the casing for each plug.</p> <p>5) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.</p>

### **Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
400711443	FORM 6 INTENT SUBMITTED
400711445	WELLBORE DIAGRAM
400711446	PROPOSED PLUGGING PROCEDURE

Total Attach: 3 Files

### **General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Form 10 (doc # 400580512) approved.	11/14/2014 8:32:00 AM
Permit	ON HOLD: w/o form 10 approval (doc # 400580512)	10/29/2014 12:01:36 PM
Permit	Well Completion Report dated 5/29/2007.	10/29/2014 11:58:10 AM

Total: 3 comment(s)