

State of Colorado  
Oil and Gas Conservation Commission1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109

DE	ET	OE	ES
Document Number: <b>400747956</b>			
Date Received:			

## SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120	Contact Name Cheryl Light
Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP	Phone: (720) 929-6461
Address: P O BOX 173779	Fax: (720) 929-7461
City: DENVER State: CO Zip: 80217-3779	Email: cheryl.light@anadarko.com

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- 123 26903 00	OGCC Facility ID Number: 296783
Well/Facility Name: TALLGRASS	Well/Facility Number: 16-17
Location QtrQtr: SESE Section: 17 Township: 1N Range: 68W Meridian: 6	
County: WELD Field Name: WATTENBERG	
Federal, Indian or State Lease Number:	

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

## CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

## LOCATION CHANGE (all measurements in Feet)

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:Change of **Surface** Footage **To** Exterior Section Lines:Current **Surface** Location **From** QtrQtr SESE Sec 17New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:Current **Top of Productive Zone** Location **From** Sec 17New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_Change of **Bottomhole** Footage **From** Exterior Section Lines:Change of **Bottomhole** Footage **To** Exterior Section Lines:Current **Bottomhole** Location Sec 17 Twp 1NNew **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,  
property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
1016	FSL	1274	FEL
Twp 1N	Range 68W	Meridian 6	
Twp	Range	Meridian	
553	FSL	521	FEL
Twp 1N	Range 68W		
Twp	Range		
553	FSL	521	FEL
Twp 1N	Range 68W		
Twp	Range		

\*\*

\*\*

\*\* attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name TALLGRASS Number 16-17 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ **CENTRALIZED E&P WASTE MANAGEMENT FACILITY:** Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

**ENGINEERING AND ENVIRONMENTAL WORK**

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

**TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK**

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT                      Approximate Start Date    12/22/2014

☐ REPORT OF WORK DONE                      Date Work Completed    \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

1 Well already has directional survey.  
2 Call foreman/field coordinator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.  
3 If unable to catch plunger, MIRU SL. Fish plunger and tag PBMD (should be 8137'). Otherwise, use rig to tag fill with tbq. Inform engineer of tag depth.  
4 Prepare location for base beam rig.  
5 Spot 25 jts of 2-3/8" 4.7# J-55 8RD EUE tbq.  
6 Spot 1800' of 1-1/4" 2.33# J-55 10rd IJ tbq.  
7 MIRU WO rig. Kill well with fresh water and biocide. ND WH, NU BOP.  
8 PU tbq to break any possible sand bridges. Do not exceed 80% of tubing tensile strength, or 57,384 lb. LD landing jt.  
9 MIRU EMI equipment. TOO H with 2-3/8" tbq. EMI tbq while TOO H. Lay down jts with wall loss or penetrations >35%. Replace jts as necessary. Keep yellow and blue band tbq. Note jt number and depth of tubing leak(s) on production equipment failure report in OpenWells. Clearly mark all junk (red band) tbq sent to yard.  
10 PU and TIH with 238 jts of 2-3/8" tbq with 4-1/2" RBP (4-1/2" 11.6# I-80). Set RBP at +/- 7510' (Collars at 7490' and 7532'). Spot 2 sx sand on top of RBP. TOO H. Stand back tbq.  
11 Pressure test RBP to 1000 psi for 15 minutes. If pressure test passes, proceed.  
12 ND BOP, ND tbq head. Unland 4-1/2" 11.6# I-80 csg (Do not exceed 130,000-lb pull weight). NU double entry flange, NU BOP.  
13 PU and TIH with 1-1/4" tbq outside 4-1/2" csg to 1700' (should be +/- 53 jts).  
14 Circulate and condition hole with ~115 bbls of water with rig pump (1.5x annular volume from 1700'), or until well is completely dead. Spot 40 bbls of 10 ppg drilling mud.  
15 TOO H with 6 jts 1-1/4" tbq to 1500'.  
16 MIRU cement company. Commence pumping cement job consisting of 5 bbls fresh water, 20 bbls sodium metasilicate and 5 bbls fresh water followed with 115 sx of Control Set "C" cement with 1/4 lb/sk cello-flake mixed at 13.5 ppg and 1.74 cf/sk (cement from 1500' to 874'. 8.25" hole avg from caliper, adding 20% excess).  
17 TOO H with 25 jts of 1-1/4" tbq to +/- 700' and circulate with drilling mud to clean up.  
18 TOO H with remaining 1-1/4" tbq and LD.  
19 RMDO cement company.  
20 ND BOP, ND double entry flange, re-land 4-1/2" csg. NU BOP.  
21 Leave well SI for minimum of 24 hours.  
22 MIRU WL and run CCL-GR-CBL-VDL from 1700' to surface (cement should be from +/- 1500' to 874'). If Fox Hills plug is not above 874', contact engineering for further instructions. Email logs to engineering and DJVendors@anadarko.com. RDMD WL.  
23 If tbq head is not as described, ND BOP. Install new GE 5000 psi 4-1/2" bottom threaded tbq head with 7-1/16" flanged top, 7-1/16" flanged 5000 psi tbq head adaptor with 2-1/16" studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). All valves, fittings, plugs on well head need to be rated for 5000 psi. NU BOP.  
24 Pressure test csg to 5000 psi for 15 mins. If pressure test does not hold, call engineering.  
25 TIH with 2-3/8" tbq and retrieving head to tag sand above RBP at +/- 7510'. Circulate sand off RBP, latch onto RBP and TOO H. SB tbq, LD RBP.  
26 PU and TIH with 2-3/8" NC, 2-3/8" XN, and 255 jts 2-3/8" tbq. If necessary, drop down with extra jts and circulate to cleanout sand. Land end of tbq at +/- 7997' (1 jt above top Codell perf).  
27 ND BOP, NU WH.  
28 GE should pressure test tbq head through test port on side of tbq head adaptor flange to 5000 psi for 15 mins.  
29 RMDO WO rig. Return well to production team.  
30 Clean location and swab well back to production. Notify field foreman/field coordinator of finished work and turn well back over to production team.

## CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

**Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.**

**Gas Analysis Report must be attached.**

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

### **Best Management Practices**

**No BMP/COA Type**

**Description**

--	--

Operator Comments:

--

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

### **CONDITIONS OF APPROVAL, IF ANY:**

### **General Comments**

**User Group**

**Comment**

**Comment Date**

--	--	--

Total: 0 comment(s)

### **Attachment Check List**

**Att Doc Num**

**Name**

400747960	OTHER
-----------	-------

Total Attach: 1 Files