

State of Colorado  
Oil and Gas Conservation Commission1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109

DE	ET	OE	ES
Document Number: <b>400748313</b>			
Date Received:			

## SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: <u>47120</u>	Contact Name <u>Cheryl Light</u>
Name of Operator: <u>KERR MCGEE OIL &amp; GAS ONSHORE LP</u>	Phone: <u>(720) 929-6461</u>
Address: <u>P O BOX 173779</u>	Fax: <u>(720) 929-7461</u>
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80217-3779</u>	Email: <u>cheryl.light@anadarko.com</u>

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- <u>123</u> <u>25139</u> <u>00</u>	OGCC Facility ID Number: <u>290568</u>
Well/Facility Name: <u>ST. ACACIUS</u>	Well/Facility Number: <u>29-35</u>
Location QtrQtr: <u>SWNW</u> Section: <u>35</u> Township: <u>3N</u> Range: <u>68W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Field Name: <u>WATTENBERG</u>	
Federal, Indian or State Lease Number: _____	

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

## CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

## LOCATION CHANGE (all measurements in Feet)

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:Change of **Surface** Footage **To** Exterior Section Lines:Current **Surface** Location **From** QtrQtr SWNW Sec 35New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:Current **Top of Productive Zone** Location **From** Sec 35New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_Change of **Bottomhole** Footage **From** Exterior Section Lines:Change of **Bottomhole** Footage **To** Exterior Section Lines:Current **Bottomhole** Location Sec 35 Twp 3NNew **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,  
property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
<u>1437</u>	<u>FNL</u>	<u>1101</u>	<u>FWL</u>
_____	_____	_____	_____
Twp <u>3N</u>	Range <u>68W</u>	Meridian <u>6</u>	
Twp _____	Range _____	Meridian _____	
<u>44</u>	<u>FNL</u>	<u>1311</u>	<u>FWL</u>
_____	_____	_____	_____
Twp <u>3N</u>	Range <u>68W</u>		
Twp _____	Range _____		
<u>44</u>	<u>FNL</u>	<u>1311</u>	<u>FWL</u>
_____	_____	_____	_____
			**

\*\* attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name ST. ACACIUS Number 29-35 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

**ENGINEERING AND ENVIRONMENTAL WORK**

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

**TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK**

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT                      Approximate Start Date    12/30/2014

☐ REPORT OF WORK DONE                      Date Work Completed    \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

### St. Acacius 29-35 Bradenhead Procedure

1 GYRO ran on 8/2/07.

2 Call Foreman or Lead Operator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.

3 MIRU slickline. Fish plunger from lubricator. RIH and pull the bumper spring and standing valve if necessary. RBIH with sinker bars and tag bottom. Report findings. PBMD should be at 7625'. RDMO slickline.

4 Prepare location for base beam rig.

5 Spot a minimum of 25 jts of 2-3/8", 4.7#, J-55, EUE tbq for replacement and 60 jts 1-1/4", 2.33#/ft, J-55, 10rd IJ for annular cement job.

6 MIRU WO rig and auxiliary equipment. Check pressures. Rig up 2" line from the casing head annulus to work tank. Kill well with fresh water. ND tree and adapter flange, NU BOP's.

7 PU 8-10' landing joint. TIW valve on top and screw into the tbq hanger. Back out the lock down pins and pull up on tbq string to break any possible sand bridges, unseat landing joint and lay down. Do not exceed 80% of tubing tensile strength, or 57,380-lb. Clean out as necessary to 7625'.

8 MIRU EMI equipment. TOOH with 2-3/8" tbq. EMI tbq while TOOH. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Note joint number and depth of tubing leak(s) on production equipment failure report in Open Wells. Clearly mark all junk (red band) tubing sent to yard.

9 TIH with 2-3/8" tbq and 4.5" RBP. Set RBP @ +/-7160', (collars are at 7137' and 7178'). Pressure test RBP to 1000 psi. Spot 2sx of sand on top of RBP and TOOH.

10 Bleed off pressure. ND BOP's, ND wellhead, Un-land 4 1/2" casing, NU dual entry flange, NU BOP.

11 PU 1-1/4" 2.3#/ft J-55 10rd IJ tubing, and TIH outside 4-1/2" casing in open hole to ~1800'. Circulate with the rig pump while TIH to clean up the annulus. Use two sweeps of Alcomer 74L while TIH and a final sweep at 1800'. Make sure no pressure is present on bradenhead before moving on to the next step. If gas is detected, contact engineering to discuss plan moving forward.

12 Contact Imperial mud (min of 24hrs. in advance) to bring out 40bbls of 10.0ppg mud. Pump 40bbls of mud at 1800'. Leave 1-1/4" tbq full of mud to avoid wet trip and PUH to 1600' to place cement in annulus.

13 MIRU cement services. Pump 10 bbl fresh water followed by 155sx (~48bbls) of 13.5 ppg (1.74 cuft/sk) Control Set "C" w/ 1/4 lb/sk cello-flake. Design is for coverage from ~1600' to ~795' using 8-1/2" hole size and 20% excess.

14 TOOH ~38 joints to ~400' and circulate 1.5 times the hole volume of water or until no cement returns are seen. TOOH with 1-1/4" tubing.

15 RDMO cementing company.

16 ND BOP. ND dual entry flange and crossover. Pick up and land 4-1/2" casing in slips.

17 Install new GE 5000 psi 4-1/2" bottom threaded tbq head with 7-1/16" flanged top, 7-1/16" flanged 5000 psi tbq head adaptor with 2 -1/16" studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). All valves, fittings, plugs on well head need to be rated for 5000 psi. NU BOP.

18 Leave well shut in for ~24hrs.

19 MIRU wireline and run CCL-GR-CBL-VDL from 3600' to surface. If new top of cement is below 795' notify Engineering. In addition to normal handling of logs/job summaries, email copies of all cement job logs/job summaries and invoices to rscDJVendors@anadarko.com within 24 hours of the completion of the job.

20 RDMO wireline.

21 PU and TIH with 2-3/8" tbq and retrieving head. Circulate sand off RBP at @ +/-7160'. TOOH with RBP and SB tbq.

22 TIH with 2-3/8" NC, 2-3/8" XN SN and 2-3/8" 4.7# J55 EUE tbq, circulate out fill if necessary to 7625'. Land tbq @ +/- 7455' (1 jt above top Codell perf).

23 Broach tubing to seating nipple. ND BOP's, NU master valve and tubing head adaptor.

## CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

**Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.**

**Gas Analysis Report must be attached.**

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

### **Best Management Practices**

**No BMP/COA Type**

**Description**

--	--

Operator Comments:

24 GE should pressure test tbq head through test port on side of tbq head adaptor flange to 5000 psi for 15 mins.  
25 RDMO WO rig.  
26 Clean location and swab well back to production. Notify Field Foreman/Field Coordinator of finished work and turn well back over to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

### **CONDITIONS OF APPROVAL, IF ANY:**

### **General Comments**

**User Group**

**Comment**

**Comment Date**

--	--	--

Total: 0 comment(s)

### **Attachment Check List**

**Att Doc Num**

**Name**

400748314	OTHER
-----------	-------

Total Attach: 1 Files