

Document Number:
400770831

Date Received:
01/14/2015

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Jenifer Hakkarinen
 Name of Operator: PDC ENERGY INC Phone: (303) 8605800
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required, Name: Rains, Bill Tel: (970) 590-6480
 Email: bill.rains@state.co.us

COGCC contact: _____

API Number 05-123-21695-00 Well Number: 21-29
 Well Name: J&L FARMS
 Location: QtrQtr: NENW Section: 29 Township: 6N Range: 63W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.462860 Longitude: -104.464110
 GPS Data:
 Date of Measurement: 09/29/2008 PDOP Reading: 1.7 GPS Instrument Operator's Name: Holly L. Tracy
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other Failed MIT
 Casing to be pulled: Yes No Estimated Depth: 3200
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: During MIT testing PDC found holes in casing from 2535'-2538'- as well as 2765-2798'. Set cast iron bridge plug at 6695' with 2sx of cement on top. See doc # 400743913

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6745	6753			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	363	130	363	0	
1ST	7+7/8	4+1/2	10.5	6,952	220	6,952	3,246	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6680 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 3100 ft. to 4700 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
Set 200 sacks half in. half out surface casing from 600 ft. to 0 ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Plugging Procedure
Codell
Existing Perforations:
Codell: 6745'-6753'
PBSD: 6952'
8 5/8" 24# @ 363' w/ 130 sks cmt
4 1/2" 10.5# @ 6952' w/ 220 sks cmt (TOC @ 3246')
Procedure:
1. MIRU wireline
2. RIH set CIBP @ 6680'
3. RIH w/dump bailer and dump 2 sx cement on top of CIBP @ 6680'
4. RIH w/ casing cutter, cut @ 3200'
5. TIH set 175 Parkman/Sussex/stub plug (3100'-4700')
6. TOH and set 200 sack cement plug half in half out of surface casing from 600' to surface
7. Cut casing and weld on cap

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: JEnifer Hakkarinen
Title: Regulatory Tech Date: 1/14/2015 Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 1/15/2015

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 7/14/2015

COA Type

Description

Attachment Check List

Att Doc Num

Name

400770831	FORM 6 INTENT SUBMITTED
400770860	WELLBORE DIAGRAM
400770861	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group

Comment

Comment Date

#Error	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) For 500' plug: pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 344' or shallower. Leave at least 100' of cement in the wellbore for each plug. 3) Properly abandon flowlines as per Rule 1103. Once properly abandoned, file electronic form 42.	1/15/2015 10:27:13 AM
#Error	Well completion report DocNum 1158487 10/31/2003	1/14/2015 3:03:19 PM

Total: 2 comment(s)