


\*NOTE:

- 1.) 10% Swell Factor Applied to Earthwork Cut Volume.
- 2.) Topsoil Volume Based on 12" Soil Depth.
- 3.) Total Disturbed Area =  $\pm X.X$  ac.
- 4.) Use Excess Pit Material to Complete Pad Surface.

SCALE: 1" = 80'  
DATE: 12/16/14  
PLAT: 2 of 7  
PROJECT: Valley  
DFT: cs

# Construction Plan Prepared for:



WPX Energy Rocky Mountain, LLC

---

*RMV 95-21 Drill Pad - Plat 2*

**Facility Layout Drawing**