

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400780303			
Date Received: 01/26/2015			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number:	100185	Contact Name	Toby Sachen
Name of Operator:	ENCANA OIL & GAS (USA) INC	Phone:	(720) -876-5845
Address:	370 17TH ST STE 1700	Fax:	()
City:	DENVER	State:	CO
Zip:	80202-5632	Email:	toby.sachen@encana.com

Complete the Attachment
Checklist

OP OGCC

API Number :	05-	123	10432	00	OGCC Facility ID Number:	242641			
Well/Facility Name:	RUHL	Well/Facility Number:	1						
Location QtrQtr:	NENE	Section:	32	Township:	2N	Range:	64W	Meridian:	6
County:	WELD	Field Name:	WATTENBERG						
Federal, Indian or State Lease Number:									

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location * ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr **NENE** Sec **32**

New **Surface** Location **To** QtrQtr _____ Sec _____

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec _____

New **Top of Productive Zone** Location **To** Sec _____

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec _____ Twp _____

New **Bottomhole** Location Sec _____ Twp _____

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,

property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

FNL/FSL		FEL/FWL	
990	FNL	990	FEL
Twp 2N	Range 64W	Meridian 6	
Twp	Range	Meridian	
			**
Twp	Range		
Twp	Range		
			**
			** attach deviated drilling plan

CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT				
Objective Formation	Formation Code	Spacing Order Number	Unit Acreage	Unit Configuration

OTHER CHANGES

☐ REMOVE FROM SURFACE BOND
 Signed surface use agreement is a required attachment

☐ CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER

From:
 Name
 RUHL
 Number
 1
 Effective Date:

To:
 Name
 Number

☐ ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number has not been drilled.
 ☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number has not been constructed (Permitted and constructed pit requires closure per Rule 905)
 ☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number:

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.
 ☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.

☐ REQUEST FOR CONFIDENTIAL STATUS

☐ DIGITAL WELL LOG UPLOAD

☐ DOCUMENTS SUBMITTED
 Purpose of Submission:

RECLAMATION

INTERIM RECLAMATION

☐ Interim Reclamation will commence approximately _____
Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.
Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

Field inspection will be conducted to document Rule 1003.e. compliance

FINAL RECLAMATION

☐ Final Reclamation will commence approximately _____
Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

Field inspection will be conducted to document Rule 1004.c. compliance

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

☐ SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 02/15/2015

☐ REPORT OF WORK DONE Date Work Completed _____

- | | | |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare | <input type="checkbox"/> E&P Waste Mangement Plan |
| <input type="checkbox"/> Change Drilling Plan | <input checked="" type="checkbox"/> Repair Well | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. | |
| <input type="checkbox"/> Other _____ | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases | |

COMMENTS:

Ruhl 1-32 DRAFT FH Remediation Workover
Pull tubing and lay down. Unland casing and pump annular fill, Run CBL, Drill out and Land tubing.
Procedure:
1. Hold a pre-job safety meeting. Discuss all aspects of the procedure with any involved personnel. Identify and address any safety concerns before the job begins.
2. MIRU pulling unit. Ensure well is dead (CIBP @ 7600').
3. ND wellhead, NU BOP.
4. POOH with tubing. Replace joints as needed.
5. Un-land 4-1/2" production casing.
6. RIH down 4-1/2" by 8-5/8" annulus with 1-1/4" tubing to 1100'.
7. Establish circulation and pump 200 sxs of class G neat cement, taking returns up annulus to surface.
8. Ensure that all cementing work complies with COGCC rule 317.i (listed on previous page).
9. POOH and lay down 1-1/4" tubing. Top off cement as necessary.
10. Re-land 4-1/2" casing
11. Run CBL and log from 1500' to surface.
12. RD E-line.
13. RIH with tubing and bit and drill up CIBP @ 7600'.
14. Pump off bit and land 2-3/8" tubing @ 7620'
15. ND BOP, NU 5K wellhead.
16. RDMO Workover rig.

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million)

Date of Measurement or Sample Collection _____

Date Run: 1/29/2015 Doc [#400780303]

Page 3 of 5

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

Best Management Practices

No BMP/COA Type

Description

--	--	--

--

Signed: _____ Print Name: Toby Sachen

Title: Regulatory Analyst Email: toby.sachen@encana.com Date: 1/26/2015

COGCC Approved: SCHLAGENHAUF, MARK Date: 1/29/2015

COA Type

Note change in workover procedure:

- 1) No CBL on file. Please submit existing or run new CBL to verify the top of primary or squeezed cement is at least 200' over Niobrara. If adequate Niobrara coverage not present provide remedial cement at least 200' above Niobrara.
- 2) Provide aquifer cement coverage from 1100' to at least 179' (50' inside surface casing shoe).
- 3) The additional cement referenced shall be placed as indicated and comply with Rule 317.j. The placed cement shall be verified with a CBL and documented with a Form 5 Drilling Completion Report.
- 4) Please submit gyro survey data with Form 5 Drilling Completion Report.

User Group

Comment

Comment Date

Total: 0 comment(s)

Att Doc Num

Name

400780303	FORM 4 SUBMITTED
400780310	OPERATIONS SUMMARY
400780325	WELLBORE DIAGRAM

Total Attach: 3 Files