

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400785135			
Date Received:			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name Cheryl Light
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment
Checklist

OP OGCC

API Number : 05- 123 31243 00 OGCC Facility ID Number: 416052
 Well/Facility Name: MCGUCKIN H Well/Facility Number: 32-32
 Location QtrQtr: NWSW Section: 32 Township: 3N Range: 65W Meridian: 6
 County: WELD Field Name: WATTENBERG
 Federal, Indian or State Lease Number: _____

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

- Change of Location * As-Built GPS Location Report As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
 Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

FNL/FSL		FEL/FWL	
<input type="text" value="2519"/>	<input type="text" value="FSL"/>	<input type="text" value="180"/>	<input type="text" value="FWL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr Sec Twp Range Meridian
 New **Surface** Location **To** QtrQtr Sec Twp Range Meridian

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec Twp
 New **Top of Productive Zone** Location **To** Sec Twp

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Bottomhole** Footage **From** Exterior Section Lines:

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec Twp
 New **Bottomhole** Location Sec Twp

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

** attach deviated drilling plan

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,
 property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

NOTICE OF INTENT Approximate Start Date 02/16/2015

REPORT OF WORK DONE Date Work Completed _____

<input type="checkbox"/> Intent to Recomplete (Form 2 also required)	<input type="checkbox"/> Request to Vent or Flare	<input type="checkbox"/> E&P Waste Mangement Plan
<input type="checkbox"/> Change Drilling Plan	<input checked="" type="checkbox"/> Repair Well	<input type="checkbox"/> Beneficial Reuse of E&P Waste
<input type="checkbox"/> Gross Interval Change	<input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request.	
<input type="checkbox"/> Other _____	<input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases	

COMMENTS:

1 MWD Survey on 2/27/2012.
 2 Call Foreman or Lead Operator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.
 3 MIRU slickline. Fish plunger from lubricator. RIH and pull the bumper spring and standing valve if necessary. RBIH with sinker bars and tag bottom. Report findings. PBMD should be at 7864'. RDMO slickline.
 4 Prepare location for base beam rig.
 5 Spot a minimum of 1610' of 1-1/4" work string for annular cement job.
 6 MIRU WO rig and auxiliary equipment. Check pressures. Rig up 2" line from the casing head annulus to work tank. Kill well with fresh water. ND tree and adapter flange, NU BOP's.
 7 PU 8-10' landing joint. TIW valve on top and screw into the tbg hanger. Back out the lock down pins and pull up on tbg string to break any possible sand bridges, unseat landing joint and lay down. Do not exceed 80% of tubing tensile strength, or 57,380-lb.
 8 MIRU EMI equipment. TOOH with 2-3/8" tbg. EMI tbg while TOOH. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Note joint number and depth of tubing leak(s) on production equipment failure report in Open Wells. Clearly mark all junk (red band) tubing sent to yard.
 9 TIH with 2-3/8" tbg and 4.5" RBP. Set RBP @ +/-6980', (collars are at 6952' and 6995'). Pressure test RBP to 1000 psi. Spot 2sx of sand on RBP and TOOH.
 10 Bleed off pressure. ND BOP's, ND wellhead, Un-land 4 1/2" casing, NU dual entry flange, NU BOP.
 11 PU 1-1/4" 2.3#/ft J-55 10rd IJ tubing, and TIH outside 4-1/2" casing in open hole to ~1610'. Circulate with the rig pump while TIH to clean up the annulus. Use two sweeps of Alcomer 74L while TIH and a final sweep at 1610'. Make sure no pressure is present on bradenhead before moving on to the next step. If gas is detected, contact engineering to discuss plan moving forward.
 12 Contact Ed Asuchak (min of 24hrs. in advance) to bring out 40bbbls of 10.0ppg mud. Pump 40bbbls of mud at 1610'. Leave 1-1/4" tbg full of mud to avoid wet trip and PUH to 1410' to place cement in annulus.
 13 MIRU cement services. Pump: 5 bbl water w/biocide, 20 bbl Sodium Metasilicate, and another 5 bbl spacer immediately preceding cement. Pump 247 cu ft/145 sx of Control Set "C" cement with 1/4 lb/sk cello-flake mixed at 13.5 ppg and 1.74 cf/sk (cement from 1410' to 760'. 9" OH avg from caliper, adding 20% excess).
 14 PUH to 500' and circulate 1.5 times the hole volume of water or until no cement returns are seen. TOOH with 1-1/4" tubing.
 15 RDMO cementing company.
 16 ND BOP. ND dual entry flange and crossover. Pick up and land 4-1/2" casing in slips.
 17 Install new GE 5000 psi 4-1/2" bottom threaded tbg head with 7-1/16" flanged top, 7-1/16" flanged 5000 psi tbg head adaptor with 2 -1/16" studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). All valves, fittings, plugs on well head need to be rated for 5000 psi. NU BOP.
 18 Leave well shut in for ~24hrs.
 19 MIRU wireline and run CCL-GR-CBL-VDL from 2000' to surface. If new top of cement is below 760' notify Engineering. In addition to normal handling of logs/job summaries, email copies of all cement job logs/job summaries and invoices to rscDJVendors@anadarko.com within 24 hours of the completion of the job.
 20 RDMO wireline.
 21 PU and TIH with 2-3/8" tbg and retrieving head. Circulate sand off RBP at @ +/-6980'. TOOH with RBP and SB tbg.
 22 TIH with 2-3/8" NC, 2-3/8" XN SN and 2-3/8" 4.7# J55 EUE tbg, circulate out fill if necessary to 7820'. Land tbg @ +/- 7705' (1 jt above top J-Sand perf).
 23 Broach tubing to seating nipple. ND BOP's, NU master valve and tubing head adaptor.
 24 GE should pressure test tbg head through test port on side of tbg head adaptor flange to 5000 psi for 15 mins.
 25 RDMO WO rig.

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million) Date of Measurement or Sample Collection _____

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

Best Management Practices

No BMP/COA Type

Description

<u>No BMP/COA Type</u>	<u>Description</u>

Operator Comments:

26 Clean location and swab well back to production. Notify Field Foreman/Field Coordinator of finished work and turn well back over to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: _____

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY:

General Comments

User Group

Comment

Comment Date

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)

Attachment Check List

Att Doc Num

Name

400785136	OTHER
-----------	-------

Total Attach: 1 Files