

US ROCKIES REGION

Anadarko Daily Summary Report

Well: UPRR 43 PAN AM UT Y 1

Project: COLORADO-WELD-NAD83-UTM13

Site: UPRR 43 PAN AM UT Y 1

Rig name no.: ECWS 7/7

Event: RE ENTER

Start date: 11/24/2014

End date: 2/10/2015

Spud date: 8/10/1985

Active datum: RKB @5,090.00usft (above Mean Sea Level)

UWI: NE/NW/0/1/N/68/W/14/0/0/6/PRIME/N/660.00/W/0/0/0/0

Report no.	Report date	MD (usft)	24 hr summary
1	11/24/2014		MIRU. Lay out all lines. Raise floors. Spot tbg. SDFN.
2	11/25/2014		Waited till noon on BOP & DC. SDFN.
3	11/26/2014		NUBOP. TIH w/ 7 7/8 rock bit. Tag at 20'. Drill cement to 30'. Started getting water back around WH. SDFN.
4	12/01/2014		Ground was sinking in under rig beam. RDMO.
5	01/13/2015		MIRU. NUBOP. PU DC, PS. Strip on 7 7/8 rock bit. Drill cement to 41' SDFN.
6	01/14/2015		Drill cement to 60'. Getting good returns (gravel) w/ no loss off fluid. SDFN.
7	01/15/2015		Drill out cement to 90'. still getting fine gravel back in returns. SDFN.
8	01/16/2015		Drill out cement to 123'. Getting fine gravel back in returns. SDFN.
9	01/19/2015		Drill cement. Fell out of cement at 138. LD PS. TIH w/ 2 7/8 WS to cement tag at 635. Drill out cement to 757. Circ clean. SDFN.
10	01/20/2015		Drill cement. Fell thru at 820. Wash down to 2500. Getting heavy mud back in returns. Getting some gas back in returns. SDFN.
11	01/21/2015		Work on rig. Tried to circ. Plugged off at bit. TOO. LD DC. SDFN.
12	01/22/2015		TIH w/ 7 7/8 bit. Circ at 1500, 2500. Drill out cement. Fell thru at 2550. Circ to 2580. TOO. SDFN.
13	01/23/2015		TIH. Tag at 2580. PU PS. Drill out to 2940. Getting mud & some cement back in returns. Circ. TOO. SDFN.
14	01/24/2015		TIH. PU PS. Drill thru tight spot at 2660. Drill to 3000'. Lost circ. TOO. SDFN.
15	01/25/2015		TIH. PU PS. Clean out to csg stub at 3344. Circ clean. TOO. SDFN.
16	01/26/2015		TOO. Strip off bit. TIH w/ muleshoe. Try to sting into csg st 3344. Could not get in csg. Ran Gyro survey from surface to 3300. TOO. SDFN.
17	01/27/2015		TIH. EOT = 3344. RU Sanjel. Pump 190 sx G cement. Had good returns thru out job. TOO. SDFN.
18	01/28/2015		TIH. Tag cement at 3005. TOO & LD tbg. EOT = 1430. RU Sanjel. Pumped 600 sx Type 3 cement. Got 5 BBL cement back to tank. TOO & LD tbg. Clean up eq. SDFN.
19	01/29/2015		ND bird bath. RU Pioneer. Tag cement at 121'. Set 8 5/8 CIBP at 82'. Test CIBP to 1000 PSI for 15 min. Held good. NDBOP. RDMO.
20	02/10/2015		Crew travel, safety. Dug up surface casing. Cut casing 6' below GL. Tagged @ 75'. Filled casing stub with 24 bags 5000# cement. Capped with a metal plate containing well info. Backfilled.
21	02/10/2015		TIME : 15:00, ROUTE : W35, WINS: H8951, PROJECT TYPE: RE-ENTER P&A, PROD: NB/CD, BATT#: N/A, GATHERER: N/A, STATION: N/A, LINE : N/A, COMMENTS: RE-P&A'd OFFLINE.