

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: Cheryl Light
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217- Email: cheryl.light@anadarko.com

For "Intent" 24 hour notice required, Name: Carlile, Craig Tel: (970) 629-8279
 Email: craig.carlile@state.co.us

COGCC contact:

API Number 05-123-23610-00 Well Name: DAVIS Well Number: 19-15
 Location: QtrQtr: SWSW Section: 15 Township: 3N Range: 67W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.221440 Longitude: -104.882710
 GPS Data:
 Date of Measurement: 06/21/2006 PDOP Reading: 3.3 GPS Instrument Operator's Name: STEVE FISHER
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 1000
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7114	7134			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	800	595	800	12	VISU
1ST	7+7/8	4+1/2	11.6	7,262	570	7,262	2,942	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7060 with 40 sacks cmt on top. CIBP #2: Depth 80 with 25 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 7060 ft. to 6440 ft. Plug Type: CASING Plug Tagged:
Set 40 sks cmt from 4310 ft. to 3810 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 140 sacks half in. half out surface casing from 1100 ft. to 700 ft. Plug Tagged:

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

5. MIRU, kill as necessary using clean fresh water with biocide. NDWH. NUBOP. Unseat landing jt, LD.
6. Notify cementers to be on call. Provide volumes listed below:
 - 6.1 Niobrara plug: 40 sx (55 cu-ft) "G" w/ 20% silica flour, 0.4% CD-32, 0.4 ASA-301 and R-3 to achieve 2:30 pump time. Mix at 15.8 ppg and 1.38 cu-ft/sk. Cement volume based on 620' in 4 1/2" casing.
 - 6.2 Sussex plug: 40 sx (46 cu-ft) "G" w/ 0.4% CD-32, 0.4% ASA-301, mixed at 15.8 ppg and 1.15 cu-ft/sk. Cement volume based on 500' in 4 1/2" casing.
 - 6.3 Foxhills plug: 140 sx (186 cu-ft) Type III w/cello flake and CaCl2 as necessary, mixed at 14.8 ppg and 1.33 cu-ft/sk. Cement volume based on 100' in 4 1/2" casing, 200' in a 9" OH with 20% excess, and 200' in 8 5/8" casing. Caliper on file.
7. TOOH 2 3/8" tubing landed at 7080'. Stand back 2 3/8" tubing.
8. MIRU WL. RIH gauge ring for 4 1/2" 11.6# casing to 7100'. POOH.
9. PU 4 1/2" 11.6# CIBP and RIH w/WL. Set at +/- 7060' to abandon Codell perms. PT to 1000 psi for 15 minutes. RDMO WL.
10. RIH with 2 3/8" tubing to +/- 7060', tag CIBP and PUH 5'. Hydrotest tubing to 3000 psi while RIH.
11. RU cementers. Pump Niobrara plug: 40 sx (55 cu-ft) "G" w/ 20% silica flour, 0.4% CD-32, 0.4 ASA-301 and R-3 to achieve 2:30 pump time. Mix at 15.8 ppg and 1.38 cu-ft/sk. Plug to cover 6440' – 7060'.
12. PUH to +/- 6200'. Reverse circulate with biocide treated water to displace cement and clear tubing.
13. PUH to +/- 4310'.
14. RU cementers. Pump Sussex plug: 40 sx (46 cu-ft) "G" w/ 0.4% CD-32, 0.4% ASA-301, mixed at 15.8 ppg and 1.15 cu-ft/sk. Plug to cover 3810' – 4310'.
15. PUH to ~3600'. Reverse circulate with biocide treated water to displace cement and clear tubing.
16. WOC per cement company recommendation. Tag cement at or above 3810'. If not, consult with Evans Engineering.
17. P&SB 1100', LD remainder.
18. RU WL. Shoot off 4 1/2" casing at or below 1000'. RD WL. Circulate casing with biocide treated water to remove any gas.
19. NDBOP, NDTH.
20. Install BOP on casing head with 4 1/2" pipe rams.
21. TOOH 4 1/2" casing, LD.
22. RIH with 2 3/8" tubing to 1100' inside 4 1/2" casing.
23. RU cementers. Establish circulation with biocide treated water and precede cement with 10 bbl SAPP and a minimum 20 bbl fresh water spacer. Pump Foxhills plug: 140 sx (186 cu-ft) Type III w/ cello flake and CaCl2 as necessary, mixed at 14.8 ppg and 1.33 cu-ft/sk. Plug to cover 1100' – 1000' in 4 1/2" casing, 1000' – 800' in 9" OH with 20% excess, and 800' – 600' in 8 5/8" casing. Caliper readings across entire interval. RD cementers.
24. PUH to 100' and circulate with biocide treated water to displace cement and clear tubing.
25. WOC per cement company recommendation. Tag cement at or above 700'. If not, consult with Evans Engineering.
26. RU WL. RIH 8 5/8" 24# CIBP to 80'. Set and pressure test to 1000 psi for 15 minutes. If tests, RDMO WL and WO rig.
27. Instruct cementing and wireline contractors to email copies of all job logs/jobs summaries to rscDJVendors@anadarko.com within 24 hours of completion of the job.
28. Supervisor is to submit paper copies of all invoices, logs, and reports to Evans Engineering Specialist.
29. Excavation crew to notify One Call to clear excavation area around wellhead and for flowlines.
30. Excavate hole around surface casing enough to allow welder to cut casing minimum 5' below ground level.
31. Welder cut casing minimum 5' below ground level.
32. Fill casing to surface using 4500 psi compressive strength cement, (NO gravel).
33. Spot weld on steel marker plate. Marker should contain well name, well number, legal location (1/4 1/4 descriptor) and API number.
34. Obtain GPS location data as per COGCC Rule 215 and send to rscDJVendors@anadarko.com.
35. Properly abandon flowlines per Rule 1103. File electronic Form 42 once abandonment complete.
36. Back fill hole with fill. Clean location, level.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light
 Title: Sr. Regulatory Analyst Date: 3/3/2015 Email: cheryl.light@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 3/13/2015

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 9/12/2015

COA Type	Description
	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) If unable to pull casing contact COGCC for plugging modifications. 3) For 1100' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 750' or shallower. 4) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400802824	FORM 6 INTENT SUBMITTED
400802830	PROPOSED PLUGGING PROCEDURE
400802831	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Well Completion Report dated 6/28/2006.	3/5/2015 1:26:35 PM

Total: 1 comment(s)