

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400809318			
Date Received:			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name Cheryl Light
Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
Address: P O BOX 173779 Fax: (720) 929-7461
City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment
Checklist

OP OGCC

API Number : 05- 123 22401 00 OGCC Facility ID Number: 273757
Well/Facility Name: BERRY Well/Facility Number: 24-8
Location QtrQtr: SWNE Section: 8 Township: 3N Range: 67W Meridian: 6
County: WELD Field Name: WATTENBERG
Federal, Indian or State Lease Number: _____

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location * ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr SWNE Sec 8

New **Surface** Location **To** QtrQtr _____ Sec _____

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec _____

New **Top of Productive Zone** Location **To** Sec _____

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec _____ Twp _____

New **Bottomhole** Location Sec _____ Twp _____

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,
property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

FNL/FSL		FEL/FWL	
2450	FNL	1420	FEL
Twp 3N	Range 67W	Meridian 6	
Twp	Range	Meridian	
			**
Twp	Range		
Twp	Range		
			**
			** attach deviated drilling plan

CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

OTHER CHANGES

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name BERRY Number 24-8 Effective Date: _____

To: Name _____ Number _____

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number _____ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number _____ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number _____ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: _____

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: _____

RECLAMATION**INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately _____

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

Field inspection will be conducted to document Rule 1003.e. compliance

FINAL RECLAMATION

☐ Final Reclamation will commence approximately _____

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

Field inspection will be conducted to document Rule 1004.c. compliance

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

☐ SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 03/30/2015

☐ REPORT OF WORK DONE Date Work Completed _____

- | | | |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare | <input type="checkbox"/> E&P Waste Mangement Plan |
| <input type="checkbox"/> Change Drilling Plan | <input checked="" type="checkbox"/> Repair Well | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. | |
| <input type="checkbox"/> Other _____ | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases | |

COMMENTS:

1 Well needs a single stage annular fill.
2 Gyro survey completed on this well 12/27/2013.
3 Contact field foreman or field coordinator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.
4 MIRU slickline. Fish PLE if necessary and tag fill (PBMD @ 7,249').
5 Prepare location for base beam rig.
6 Spot 40 joints of 2-3/8" 4.7# J-55 8RD EUE tubing.
7 Spot 45 joints of 1.66" 2.33# J-55 IJ tubing.
8 Spot Alcomer 74L for pre-cement mud flush sweeps.
9 Notify Ed Asuchak in drilling to have 10 ppg mud on standby.
10 MIRU WO rig. Kill well with fresh water with biocide. ND wellhead, NU BOP.
11 Run two 2" lines from starting head to return tanks.
12 PU 8-10' landing joint with TIW safety valve on top and screw into the tubing hanger. Back out the lock down pins and pull up on the tubing string to break any possible sand bridges. Do not exceed 80% of tubing tensile strength, or 57,384-lb.
13 Unseat tubing hanger and LD tubing hanger and landing joint. Install rubber wiper in stripping head.
14 MIRU EMI equipment. TOO H with 2 3/8" tubing. EMI tubing while TOO H. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Keep yellow and blue band tubing. Note joint number and depth of tubing leak(s) on production equipment failure report in OpenWells. Clearly mark all junk (red band) tubing sent to yard.
15 TIH 2 3/8" tubing with 4.5" RBP (4.5" 11.6# I-80). Set RBP at +/- 6,800' (Collars at 6,818' and 6,776').
16 Circulate gas out of well; pressure test RBP to 2,000 psi for 15 minutes (Pressure test to make sure plug is set correctly).
17 Spot 2 sx sand on top of RBP. TOO H with 2 3/8" tubing, SB tubing.
18 ND BOP, un-land 4 1/2" casing, RU dual-entry flange, NU BOP. Stretch calculations show that with a 65,000-lb pull weight there should be 24" of stretch. If casing cannot be safely un-landed, contact engineering for further support.
19 PU and TIH with 1.66" 2.33# IJ tubing to 1,200'. While tripping in, pump Alcomer 74L sweeps periodically based on visual inspection of returns with a final sweep at 1,200'.
20 Circulate 91 bbls biocide treated water with rig pump (circulate at least 1.5x annular volume from 1,200') with 10 ppg mud spotted at the end until well is dead.
21 TOO H 1.66" tubing to 1,000'.
22 MIRU cement company, establish circulation with biocide treated water and commence pumping cement job consisting of 5 bbls fresh water, 20 bbls sodium metasilicate, 5 bbls fresh water, and 33 bbl (140 sx) of Type III with 1/4 lb/sk cello-flake mixed at 14.8 ppg and 1.33 cuft/sk blended for a 3 hr pump time (Cement from 1,000' to 550').
23 TOO H 1.66" tubing to 400' and reverse circulate 2X tbq volume to clean up. TOO H & LD remaining 1.66" tubing.
24 Break lines, clean up with fresh water, RMDO cement company.
25 ND BOP, ND dual entry flange, re-land 4 1/2" casing, and NU BOP. Leave well shut in minimum of 24 hours.
26 MIRU WL and run CCL-GR-CBL-VDL from 3,000' to 0'. If cement coverage is not above 550', contact Evans Engineering for further instructions. Email logs to Evans Engineering and DJVendors@anadarko.com. RDMO WL.
27 TIH with 2 3/8" tubing and retrieving head and tag sand above RBP at +/- 6,800'. Circulate sand off RBP. Latch onto RBP and release RBP. TOO H standing back all 2 3/8" tubing and LD RBP.
28 PU and TIH with 2 3/8" notched collar, 2 3/8" XN nipple, and 2 3/8" 4.7# J-55 tubing. Clean out as necessary. Land 2 3/8" tubing at +/- 7,100' (1 joint above top Codell perf).
29 ND BOP, NU 7 1/16", 5,000 psi flanged tubing head adaptor w/ 2 1/16", 5,000 psi flanged master valve.
30 MIRU hydrotester. Install 2 3/8" pup joint above master valve. Hydrotest wellhead to 5,000 psi from below tubing head through master valve for 15 minutes.
31 RMDO WO rig. Return well to production team.

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million)

Date of Measurement or Sample Collection _____

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

--

Best Management Practices

No BMP/COA Type

Description

--	--

Operator Comments:

32 Clean location. Notify field foreman/field coordinator of finished work and turn well back over to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: _____

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY:

General Comments

User Group

Comment

Comment Date

--	--	--

Total: 0 comment(s)

Attachment Check List

Att Doc Num

Name

400809321	OTHER
-----------	-------

Total Attach: 1 Files