

US ROCKIES REGION			
Anadarko Daily Summary Report			
Well: GORDON TURKEY FARMS POOL #1			
Project:COLORADO-WELD-NAD83-UTM13		Site:STREAR 16-10-9F	Rig name no.:ECWS 9/9
Event: ABANDONMENT		Start date: 2/6/2015	End date: Spud date: 12/13/1970
Active datum: GL @4,957.00usft (above Mean Sea Level)		UWI: 0/2/N/67/W/10/0/SESE/6/0/0/0/0/0/0	
Report no.	Report date	MD (usft)	24 hr summary
1	02/06/2015		MIRU ECWS#9
2	02/09/2015		wait on automation removal, tbg350#,csg350#,Sfc500#, blow down/kill well, ND WH, NU BOP's, unland 2 3/8" tbg TOO H tallying, PU 4.5" csg scraper TIH to 7900', TOO H LD scraper, SWI SDFN,
3	02/10/2015		MIRU hydrotester, PU 4.5" mech set CIBP, 2 3/8" tbg, TIH hydrotesting to 6000#, set CIBP @ 7900', RDMO tester, LD 1 jt, roll gas OOH, test CIBP to 1000# for 15 mins, bad test, call office for orders, TOO H, MIRU WL, PU 4.5" CIBP RIH, see comments
4	02/11/2015		MIRU WL, PU CBL RIH, run CBL from 7900' to Sfc, LD CBL, PU 3 1/8" perf guns RIH, shoot 1' of holes @7330' and 6850', POOH RDMO WL, PU 4.5" CICR, 209 jts 2 3/8" tbg TIH, set CICR @ 6890', establish circulation w/ rig pump, see comments
5	02/12/2015		RIH 7 stands, tag TOC @ 6643', TOO H, MIRU WL, PU 3 1/8" perf guns RIH, shoot 1' of squeeze holes @ 5125' and 4360', POOH RDMO WL, PU 4.5" CICR 2 3/8" tbg TIH, set CICR @ 4400', establish circulation w/ rig pump, see comments
6	02/13/2015		TIH 1 stand, tag TOC @ 3157', TOO H laying down, 40 jts 2 3/8" plugged w/ cement, slips broke, repair slips, MIRU WL, cut CSg @ 550', POOH, RDMO WL, circulate 120 Bbls, ND BOP's/WH, unland 4.5" csg, NU BOP's/spool, LD 14 jts 4.5" csg, see comments
7	02/17/2015		PU 4 jts 2 3/8" tbg, TIH tag TOC @ 100', LD tbg, ND BOP's/WH, MIRU WL, set 8 5/8" CIBP @ 80', POOH RDMO WL, pressure test CIBP to 1000# for 15 mins, good test, RDMO ECWS#9(take rig to yard overnight)
8	03/11/2015		Crew travel, safety. Dug up surface casing. Cut casing 6' below GL. Tagged @ 83'. Filled casing stub with 42 bags 5000# cement. Capped casing with a metal plate containing well info. Backfilled.

COMMENTS:

02/10/15 - tag fluid level @ 6050', set CIBP @ 7870', POOH, PU dump bailer, dump bail 2 sx cement on CIBP, fill csg w/ water, test CIBP to 1000# for 15 mins, good test, SWI SDFN

02/11/15 - MIRU cementers, pump 170 sx suicide squeeze from 7330' to 6850' in 4.5" annulus, underdisplace 3 Bbls sting out of retainer, PUH 6 stands, circulate clean, RDMO cementers, SWI, SDFN

02/12/15 - MIRU cementers, pump 700 SX sussex suicide squeeze from 5125' to 4360', underdisplace 3 Bbls, sting out of retainer,PUH to 3150', RDMO cementers, SWI, SDFN

02/13/15 - PU 36 jts 2 3/8" tbg, TIH to 1300', MIRU cementers, pump 360 sx balance stub plug from 1300' to 100', PUH to 96', circulate clean, RDMO cementers, SWI, SDFN