

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400830056

Date Received:

04/23/2015

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10459

Contact Name: Taylor Heffner

Name of Operator: EXTRACTION OIL &amp; GAS LLC

Phone: (720) 9742019

Address: 1888 SHERMAN ST #200

Fax:

City: DENVER State: CO Zip: 80203

Email: theffner@extractionog.com

For "Intent" 24 hour notice required,

Name: Peterson, Tom

Tel: (303) 815-9641

COGCC contact:

Email: tom.peterson@state.co.us

API Number 05-123-09010-00

Well Name: JOHN HORST

Well Number: 43-21

Location: QtrQtr: NESE Section: 21 Township: 2N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: SPINDLE

Field Number: 77900

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.121706

Longitude: -104.888549

GPS Data:

Date of Measurement: 05/27/2009

PDOP Reading: 3.3

GPS Instrument Operator's Name: Joseph Dugan

Reason for Abandonment:

☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 700

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SHANNON	5142	5164			
SUSSEX	4674	4740			

Total: 2 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+3/4	8+5/8	20	585	400	585	0	VISU
1ST	7+7/8	4+1/2	9.5	5,230	350	5,230	4,047	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4580 with 43 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 110 sks cmt from 800 ft. to 435 ft. Plug Type: STUB PLUG Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 110 sacks half in. half out surface casing from 800 ft. to 435 ft. Plug Tagged: ☒

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Taylor Heffner

Title: Production Engineer Date: 4/23/2015 Email: theffner@extractionog.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 5/15/2015

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_ Expiration Date: 11/14/2015

### COA Type

### Description

	<ol style="list-style-type: none"><li>1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU.</li><li>2) If unable to pull casing contact COGCC for plugging modifications.</li><li>3) For 800' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 535' or shallower. If shoe plug not circulated to surface then place 10-40 sx inside casing at surface. Leave at least 100' for each plug.</li><li>4) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.</li><li>5) Please submit existing gyro survey data with Form 6 (s) Subsequent Report of Abandonment.</li></ol>
--	--

## Attachment Check List

**Att Doc Num****Name**

400830056	FORM 6 INTENT SUBMITTED
400830061	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

**User Group****Comment****Comment Date**

Permit	Missing production posted. Permitting Review Complete.	4/29/2015 8:51:48 AM
Permit	ON HOLD: operator requesting hold for time to get production records submitted.	4/27/2015 3:30:30 PM
Permit	Well Completion Report dated 2/16/1977.	4/27/2015 3:30:29 PM

Total: 3 comment(s)