

DE	ET	OE	ES
----	----	----	----

**Replug By Other Operator**

Document Number:  
400819876

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Justin Garrett  
 Name of Operator: NOBLE ENERGY INC Phone: (303) 228 4449  
 Address: 1625 BROADWAY STE 2200 Fax: (303) 228 4286  
 City: DENVER State: CO Zip: 80202 Email: Justin.Garrett@nblenergy.com

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277  
 COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-05656-00 Well Number: 43-14  
 Well Name: GOVERNMENT  
 Location: QtrQtr: SENE Section: 14 Township: 9N Range: 59W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.752644 Longitude: -103.938348  
 GPS Data:  
 Date of Measurement: 10/23/2014 PDOP Reading: 6.1 GPS Instrument Operator's Name: Brian Rottinghaus  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA			10/28/2014	CEMENT	

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	13+1/2	10+3/4	24.0	202	0	202	0	
1ST LINER	13+1/2	5+1/2	17	217	0	217	0	
OPEN HOLE	9+7/8			6,750				

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 6515 ft. to 6250 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 150 sks cmt from 6204 ft. to 5766 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 150 sks cmt from 3021 ft. to 2673 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 500 sks cmt from 1612 ft. to 704 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 460 sks cmt from 250 ft. to 217 ft. Plug Type: OPEN HOLE Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 10/28/2014

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: Sanjel

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

1st liner refers to a liner just cemented in to P&A well.

Additional plugs:

Set 100 sacks cement from 217 ft. to 0 ft. in Open Hole, tagged

Set 25 sacks cement from 40 ft. to 0 ft. in surface casing (top out)

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Justin Garrett

Title: Regulatory Analyst Date: \_\_\_\_\_ Email: Justin.Garrett@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400847929	CEMENT JOB SUMMARY
400847930	OTHER
400847933	WELLBORE DIAGRAM

Total Attach: 3 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)