



DE	ET	OE	ES
Document Number: 400865935			
Date Received: 07/10/2015			

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10112 Contact Name: Rachel Grant  
 Name of Operator: FOUNDATION ENERGY MANAGEMENT LLC Phone: (918) 526-5592  
 Address: 16000 DALLAS PARKWAY #875 Fax: (918) 585-1660  
 City: DALLAS State: TX Zip: 75248- Email: regulatory@foundationenergy.com

**For "Intent" 24 hour notice required,** Name: Welsh, Brian Tel: (719) 325-6919  
**COGCC contact:** Email: brian.welsh@state.co.us

API Number 05-125-06643-00 Well Name: LIPPERT Well Number: 34-25  
 Location: QtrQtr: SWSE Section: 25 Township: 4S Range: 44W Meridian: 6  
 County: YUMA Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: BONNY Field Number: 7325

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.675513 Longitude: -102.240993  
 GPS Data:  
 Date of Measurement: 09/15/2009 PDOP Reading: 2.3 GPS Instrument Operator's Name: Mary Nicklos  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	1655	1670			

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+7/8	7	17	314	80	314	0	VISU
1ST	6+1/4	4+1/2	9.5	1,770	100	1,770	785	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1605 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 400 ft. with 71 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Rachel Grant  
 Title: HSE Regulatory Date: 7/10/2015 Email: regulatory@foundationenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 7/28/2015

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 1/27/2016

COA Type	Description
	1) Provide 48 hour notice of MIRU via electronic Form 42. 2) Shoe plug: Tag (400') surface casing shoe plug 50' above shoe, if not cemented to surface as proposed. 3) Surface plug: Cement from 50' to surface in casing and annulus.

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400865935	FORM 6 INTENT SUBMITTED
400865975	WELLBORE DIAGRAM
400865976	WELLBORE DIAGRAM

Total Attach: 3 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Moved CIBP proposed at 1630' up to 1605' (50' above top perf).	7/28/2015 1:16:48 PM
Permit	Removed "date abandoned" on formation, as it is producing.	7/10/2015 8:43:10 AM

Total: 2 comment(s)