

Sunburst, Inc.

Vader 33-15 Recompletion Procedure.

After completing the J Sand formation, it produced excessive amounts of water to be profitable.

Sunburst intends to Recomplete the subject well using the below procedures;

1. Set a CIBP at 7580', dump 2 sx cement on top.
2. Perforate the Codell formation at 7162' – 7172'.
3. Frac Codell with white sand and Borate x-link fluid.
4. Set tubing