

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: <b>400990333</b>			
Date Received: <b>02/17/2016</b>			

**SUNDRY NOTICE**

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 96850 Contact Name Vicki Schoeber  
 Name of Operator: WPX ENERGY ROCKY MOUNTAIN LLC Phone: (970) 263-2721  
 Address: PO BOX 370 Fax: ( )  
 City: PARACHUTE State: CO Zip: 81635 Email: vicki.schoeber@wpxenergy.com

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- 045 10693 00 OGCC Facility ID Number: 277379  
 Well/Facility Name: FEDERAL Well/Facility Number: RWF 331-18  
 Location QtrQtr: SEnw Section: 18 Township: 6S Range: 94W Meridian: 6  
 County: GARFIELD Field Name: RULISON  
 Federal, Indian or State Lease Number: COC 62160

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

**CHANGE OF LOCATION OR AS BUILT GPS REPORT**

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

**SURFACE LOCATION GPS DATA** Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
 Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

**LOCATION CHANGE (all measurements in Feet)**

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr SEnw Sec 18

New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec \_\_\_\_\_

New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

New **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,

property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
1836	FNL	1873	FWL
Twp 6S	Range 94W	Meridian 6	
Twp	Range	Meridian	
1050	FNL	1988	FEL
Twp	Range		
Twp	Range		
1050	FNL	1988	FEL

\*\*

\*\*

\*\* attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name FEDERAL Number RWF 331-18 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ **CENTRALIZED E&P WASTE MANAGEMENT FACILITY:** Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

## ENGINEERING AND ENVIRONMENTAL WORK

### ☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

## TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 02/18/2016

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input type="checkbox"/> Repair Well  | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input checked="" type="checkbox"/> Other <u>Casing Remediation</u>  | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

WPX Energy Rocky Mountain, LLC respectfully requests to remediate corroded casing in the RWF 331-18 well. Verbal approval was received from J. Krabacher with the COGCC on 2/17/16.

### Proposed Procedure:

1. MIRU sevice rig, POOH w/ 2-3/8" tbg
2. RIH with RBP, set at 6480' with 2 sks sand to isolate perforations.
3. Prior casing tests showed possible holes from 4879'-5757', Caliper log showed no large holes or parts in casing.
4. RIH with wireline and perforate 4.5" casing at 5875', 6 shots/ft, 60 degree phasing. TOOHH with wireline.
5. RIH with 2-3/8" with cement retainer. Set cement retainer at 5520'.
6. Establish injection rate, and determine volume of cement needed to remediate section
7. Pump squeeze cement. Class G with fluid loss additive. 15.8 ppg, 1.15 ft<sup>3</sup>/sx.
8. Bleed off pressure and sting out of cement retainer.
9. TOOHH with 2-3/8" tubing, P/U HD packer, RIH with packer.
10. Set packer at 5480' to test cement retainer. If PASS go to Step 11 in procedure. If FAIL then TOOHH with packer, then RIH with RBP and packer, set RBP above cement retainer, 5510'.
11. TOOHH with packer to 5200', Test casing from packer to cement retainer to determine if more holes are present below packer. If PASS go to Step 12 of Procedure. If test FAILS attempt to get injection rate to determine squeeze cement volume then go to Step 12 of Procedure.
12. Test backside of packer. If PASS then TOOHH with packer, go to Step 14 in Procedure. If FAIL determine injection rate to determine squeeze cement volume, TOOHH with packer.
13. Pump squeeze cement if needed. WOC
14. RIH with 2-3/8" with bit to drill out cement. Testing casing to 1000 psi every connection to determine if holes
15. TOOHH with bit. RIH to retrieve TSRBP.
16. Clean out wellbore, re-land tubing and return to production
17. Submit subsequent report

Wellbore diagram and procedure attached.

## CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

--

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

## Best Management Practices

No BMP/COA Type

Description

--	--

**Operator Comments:**

WPX Energy Rocky Mountain, LLC respectfully requests to remediate corroded casing in the RWF 331-18 well. Verbal approval was received from J. Krabacher with the COGCC on 2/17/16.

Wellbore diagram and procedure attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Vicki Schoeber  
Title: Regulatory Specialist Email: vicki.schoeber@wpxenergy.com Date: 2/17/2016

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: KRABACHER, JAY Date: 2/18/2016

**CONDITIONS OF APPROVAL, IF ANY:****COA Type****Description**

--	--

**General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
Engineer	Yes, the attached procedure is pretty much as described in the phone conversation Feb. 16. Procedure will probably change wellbore configuration (cemented intervals) -- so submit Form 5 after successful completion of work with revised wellbore-cementing information.	2/18/2016 12:15:27 PM

Total: 1 comment(s)

**Attachment Check List**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>
400990333	FORM 4 SUBMITTED
400990573	WELLBORE DIAGRAM
400990574	OTHER

Total Attach: 3 Files