

**US ROCKIES REGION**  
**Operation Summary Report**

Well: **PIONEER 17-15** Spud date: 1/7/2009

Project: COLORADO-WELD-NAD83-UTM13 Site: PIONEER 17-15 PAD Rig name no.: BAYOU 23/23

Event: CONST- CAP WELL WORK Start date: 12/3/2014 End date:

Active datum: RKB @4,894.00usft (above Mean Sea Level) UWI: 0/2/N/65/W/15/0/NENE/6/PM/N/1,250.00/E/0/1,320.00/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
12/3/2014	6:30 - 7:30	1.00		35	A	P		MIRU Slickline, RIH Remove Prod. Equip.,RIH Tag @ 7752 KB, RDNO Slickline.
	7:30 - 8:30	1.00		30	A	P		MIRU BWS 23,
	8:30 - 9:30	1.00		30	E	P		Blow Down Well Control With 80 BBLs Water/Biocide.
	9:30 - 11:00	1.50		30	F	P		ND WH, NU BOP
	11:00 - 13:30	2.50		31	I	P		MIRU EMI, EMI & Tally OOH With 229 Jnts, LD 4 Bad Jnts.
	13:30 - 15:00	1.50		34	1	P		<b>MIRU Wireline, RIH CIBP Set @ 6896</b> KB, RDMO Wireline.
	15:00 - 16:00	1.00		30		P		Load Hole By Trickleing Fluid In
	16:00 - 17:00	1.00		30		P		SWI, Drained Pump, SDFN.
	17:00 - 17:30	0.50		30	G	P		Crew Travel To Yard,
12/4/2014	6:00 - 6:30	0.50		30	G	P		Crew Travel To Location.
	6:30 - 9:30	3.00		52	G	P		Load Hole, Purge To Flat Tank, PT CIBP To 1000# ,WILL NOT HOLD.
	9:30 - 11:30	2.00		31	C	P		TIH Packer, 216 Jnts Tbg,Set Packer @ 6826.51 KB.
	11:30 - 12:30	1.00		52	G	P		Load Tubing, PT To 1000# WILL NOT HOLD, PT Csg To 1000#, GOOD TEST.
	12:30 - 14:30	2.00		31	I	P		TOOH With Packer.
	14:30 - 15:30	1.00		30		P		SWI, Drain Pump, SDFD.
	15:30 - 16:00	0.50		30	G	P		Crew Travel To Yard.
12/5/2014	6:00 - 6:30	0.50		30	G	P		Crew Travel To Location.
	6:30 - 8:30	2.00		34	D	P		<b>Dump Bail @ SacksCement.</b>
	8:30 - 13:30	5.00		30		P		SWI, SDFD, Wait for Cement To Cure, Rig On Standby Time.
	13:30 - 14:00	0.50		30	G	P		Cew Travel To Yard.
12/8/2014	6:00 - 6:30	0.50		30	G	P		Crew Travel To Location.
	6:30 - 9:00	2.50		52	G	P		Trickle Load Casing, Purge To Flat Tank, PT CIBP to 1000#, WILL NOT HOLD.
	9:00 - 10:00	1.00		46	E	P		Waiting For Wireline To Get To Location.
	10:00 - 11:00	1.00		34	1	P		<b>MIRU Wireline, RIH Second CIBP Set @ 6851</b> KB.
	11:00 - 12:00	1.00		52	G	P		Load Hole, PT CIBP To 1000#, GOOD TEST.
	12:00 - 12:30	0.50		34	D	P		RIH, <b>Dump Bail 2 Sacks Cement.</b>
	12:30 - 14:00	1.50		31	I	P		TIH Bit, XN Nipple, 215 Jnts Tubing.
	14:00 - 15:00	1.00		30		P		ND BOP, NU New WH.SWI
	15:00 - 16:30	1.50		30		P		RDMO
	16:30 - 17:00	0.50		30	G	P		Crew Travel to Yard
	17:00 - 18:30	1.50		52		P		MIRU Hydro Tester,Torque & PT WH To 5000#, GOOD TEST, PT Casing To 5000#, GOOD TEST, RDMO Hydro Tester, SDFN.