

FORM
6Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400962270

Date Received:

12/31/2015

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Jenifer Hakkarinen

Name of Operator: PDC ENERGY INC

Phone: (303) 8605800

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required,

Name: Gomez, Jason

Tel: (970) 573-1277

COGCC contact:

Email: jason.gomez@state.co.us

API Number 05-123-24014-00

Well Name: CECIL

Well Number: 31-26

Location: QtrQtr: NWNE Section: 26 Township: 7N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.549750

Longitude: -104.514440

GPS Data:

Date of Measurement: 09/29/2006

PDOP Reading: 1.9

GPS Instrument Operator's Name: H.L. TRACY

Reason for Abandonment: ☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7040	7050	11/09/2015	B PLUG CEMENT TOP	6700
NIOBRARA	6752	6878	11/09/2015	B PLUG CEMENT TOP	6700

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/2	8+5/8	24	587	325	587	0	
1ST	7+7/8	4+1/2	10.5	7,229	810	7,229	0	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 70 sacks half in. half out surface casing from 800 ft. to 0 ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Cecil #31-26 (05-123-24014)/Plugging Procedure (Intent)
Producing Formation: Abandoned Nobrara-Codell
Abandoned Perforations: Niobrara 6752'-6878' Codell 7040'-7050'
Existing CIBP: Set at 6700' with 2 sxs cement
TD: 7244' PBD: 7200'

Surface Casing: 8" 24# @ 587' w/ 325 sks cmt.

Production Casing: 4 1/2" 10.5# @ 7229' w/ 810 sks cmt (TOC @ Surface - CBL).

Note: Production casing was pressure tested to 500 psi on 11/6/2015.

Tubing: 2" 9.7# tubing at 6671'. (11/9/2015).

Proposed Procedure:

1. MIRU wireline company. Run gyro survey.
2. MIRU pulling unit. Pull and reset 2" tubing at 800'.
3. Mix and pump 70 sxs of 15.8#/gal CI G cement. Cement should circulate to surface.
4. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jenifer Hakkarinen

Title: Reg Tech Date: 12/31/2015 Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 1/19/2016

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 7/18/2016

COA Type**Description**

	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) For 800' plug: pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 537' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the wellbore for each plug. 3) Properly abandon flowlines. Once flowlines are properly abandoned, file electronic form 42.
--	--

Attachment Check List**Att Doc Num****Name**

400962270	FORM 6 INTENT SUBMITTED
400962273	WELLBORE DIAGRAM
400962274	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments**User Group****Comment****Comment Date**

Permit	Permit tast complete.	1/5/2016 3:17:33 PM
Public Room	Document verification complete 01/04/16	1/4/2016 3:11:26 PM

Total: 2 comment(s)