

Document Number:  
401074081

Date Received:  
07/06/2016

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Kelsi Welch

Name of Operator: PDC ENERGY INC Phone: (303) 831-3974

Address: 1775 SHERMAN STREET - STE 3000 Fax: \_\_\_\_\_

City: DENVER State: CO Zip: 80203 Email: kelsi.welch@pdce.com

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277

**COGCC contact:** Email: jason.gomez@state.co.us

API Number 05-123-15978-00

Well Name: MOWERY Well Number: 19-2

Location: QtrQtr: SESE Section: 19 Township: 5N Range: 64W Meridian: 6

County: WELD Federal, Indian or State Lease Number: 68976

Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.378889 Longitude: -104.585556

GPS Data:  
Date of Measurement: 07/03/2010 PDOP Reading: 1.9 GPS Instrument Operator's Name: Shantell Kling

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: 515

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6890	6901			
NIOBRARA	6592	6794			

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	315	220	315	0	VISU
1ST	7+7/8	3+1/2	9.3	7,023	200	7,023	6,135	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6550 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 220 sacks half in. half out surface casing from 565 ft. to 0 ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Mowery #19-2 (05-123-15978)/Plugging Procedure (Intent)  
Producing Formation: Niobrara 6592'-6794' Codell 6890'-6901'  
TD: 7023' PBDT: 6932'  
Surface Casing: 8" 24# K-55 @ 315' w/ 220 sks cmt.  
Production Casing: 3½" 9.3# J-55 @ 7023' w/ 200 sks cmt (TOC 6078'CBL).

Tubing: 1½" 2.9# J-55 EUE set at 6885'. (10/3/2014)

Proposed Procedure:

1. MIRU RU pulling unit. Pull 1½" tubing.
2. RU wireline company. TIH with CIBP. Set bridge plug at 6550'. TIH with dump bailer. Spot 2 sxs cement on top of CIBP.
3. TIH with casing cutter. Cut 3½" casing at 515'. Pull 3½" casing.
4. TIH with tubing to 565'. Mix and pump 220 sxs of 15.8#/gal CI G cement. Cement should circulate to surface.
5. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Kelsi Welch

Title: Regulatory Analyst Date: 7/6/2016 Email: kelsi.welch@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 7/14/2016

**COA Type**

**Description**

	<p>1) Provide 48 hour notice of plugging MIRU via electronic Form 42.                  2) For the 565' plug: pump plug and displace. If surface casing plug is not circulated to surface then tag plug – must be at 265' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the casing for each plug.                  3) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.                  4) Prior to initiation of plugging operations, a Bradenhead test shall be performed. If any pressure remains at the conclusion of the test or any liquids were present call COGCC Engineer for sampling requirements. Form 17 shall be submitted within 10 days.</p>
--	---

**Attachment Check List**

**Att Doc Num**

**Name**

401074081	FORM 6 INTENT SUBMITTED
401074094	WELLBORE DIAGRAM
401074095	WELLBORE DIAGRAM

Total Attach: 3 Files

**General Comments**

**User Group**

**Comment**

**Comment Date**

Public Room	Document verification complete	7/7/2016 10:14:47 AM
-------------	--------------------------------	-------------------------

Total: 1 comment(s)