

Date of last WO:

PUR or UZ:

Objective: Plug and abandon well

BWO:

cc:

Final report cc: Adam, Paula W, Well File

8/26/14 Spot in Yetter Rig #9. SD
8/27/14 Set CIBP @ 5550', dump bail 2 sks cement on top of plug. Found free point at 1035'. Shoot off casing and pull 26 jts 4½" csg.
8/28/14 TIH w/tbg to csg stub at 1035', pump 50 sks cement, TOH. WOC. TIH w/tbg, tag cmt 800' FS. Pull tbg to 200', pump 50 sks ½ in ½ out of bottom of surface casing. TOH. SD
8/29/14 TIH w/ tubing, tag shoe plug 145' FS (45' low). Pump 45 sks and finish fill surface csg all the way to surface. RDMO.

FINAL REPORT