

UWHGS #1-17 WORK PLAN

To complete existing well UWHGS #1-17 for injection operations, the following workover procedure will be conducted:

- 1) MIRU on UWHGS #1-17
- 2) Open Wellhead and pull 3-1/2" 9.3# tubing (Bottom of Tubing @ 5032.51')
- 3) GIH with wireline. Latch onto Baker EA CICR set @ 5,100'. POOH
- 4) GIH with Baker Model DA 8-5/8"x 3-1/2" Drillable Packer on 3-1/2" tubing. Set Packer at 5092'
- 5) Load backside with water. Corrosion inhibitor and biocide added. Secure Wellhead. MO.