

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
6/23/2016	-							
6/24/2016	0:00 -							I have left a voicemail with the State Inspector (John Montoya) @ 7:55 AM on 6/24/16 that BASIC 1549 will be moving on to the CHAMPLIN 78 AMOCO D 1 (API# 0500107379) at 1 PM, on 6/27/16. We will tentatively be pumping our first cement job at noon on 6/29/16. Please contact me if you have any questions.
6/25/2016	11:00 - 15:00	4.00	ABANDP	34	G	P		MIRU SL. RIH AND RETRIVE PLUNGER AND SV. TAG PROFILE NIPPLE @ 7896'. RU VES. RUN GYRO FROM 7800' TO SURFACE MAKING STOPS EVERY 100'. RDMO VES. RIH AND TAG FILL AT 7976'. RDMO SL.
6/27/2016	8:00 - 9:00	1.00	ABANDP	33	1	P		NOTIFY PROD FOREMAN/FIELD COORDINATOR, MIRU FLARE EQUIP/ PULL AUTOMATION
	9:00 - 9:05	0.08	ABANDP	52	I	X		TP200/CP200/SP20, BLOW DOWN SFC TO 0# IN 5 MINUTES, NO FLUID PRODUCED, SFC REMAINED DEAD THROUGHOUT JOB
	9:05 - 10:30	1.42	ABANDP	33	F	P		BLOW DOWN CSG THROUGH FLARE TO 80#, PUMPED 55 BBLS WATER W/BIO DOWN CSG WHILE FLARING TBG TO 80#, CSG WENT ON VAC @ 3 BBLS AWAY, PUMPED 25 BBLS DOWN TBG, WENT ON VAC @ 1BBLS AWAY, 5.4 MCF'S BURNED
	10:30 - 11:00	0.50	ABANDP	33	1	P		SWI, RDMO FLARE EQUIP
	15:00 - 15:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING RIG AND EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN RIGGING UP BOPS. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL.
	15:15 - 15:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN THE REST OF THE DAY. SI AT THE END OF THE DAY.
	15:15 - 18:45	3.50	ABANDP	30	A	P		MIRU BASIC 1549. CP: 180, SC: 0, TBG: 0. SPOT IN BASE BEAM, RIG, PUMP, TWO TANKS, TBG TAILER, RUN ALL LINES TO AND FROM PUMP AND TANKS, BLOW WELL DEAD AND PUMP 20 BBLS DOWN TBG TO MAKE SURE WELL STAYS DEAD. ND MASTER VALVE AND ADAPTOR. NU BOPS. SWI. SDFN.
	18:45 - 19:30	0.75	ABANDP	30	G	P		CREW TRAVEL FROM LOCATION.
6/28/2016	6:15 - 7:00	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	7:00 - 7:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. STAY OUT FROM BEHIND THE WL TRUCK WHEN TIH.
	7:15 - 9:00	1.75	ABANDP	31	I	P		TOOH AND SB ALL 254 JTS OF 2-3/8" TBG. TBG PINS AND COLLARS LOOKED GOOD UPON INSPECTION.
	7:15 - 7:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN THE REST OF THE DAY. SI AT THE END OF THE DAY.
	9:00 - 13:00	4.00	ABANDP	31	I	P		PU AND TIH W/ 5-1/2" CSG SCRAPER ON 2-3/8" TBG DOWN TO 7900' w/ 254 JTS. TOOH, SB ALL TBG, LD BIT AND SCRAPER.
	13:00 - 16:30	3.50	ABANDP	34	I	X		MIRU RELIANCE WL. HAVE SAFETY MEETING TALKING ABOUT THE DAYS OPERATIONS. PU AND RIH W/ CCL, SETTING TOOL, AND 5-1/2" CIBP. ATTEMPT TO SET CIBP @ 7855'. GET ON DEPTH AND ATTEMPT TO FIRE SETTING TOOL. TOOL SEEMED TO ONLY PARTIALLY SET. RIH DOWN TO 7865' AND TOOL STRING WOULD STACK OUT. PUH TO 7840', TOOL STRING WOULD PULL INTO 2800 LBS OF TENSION. WORK TOOL STRING BACK AND FORTH ATTEMPTING TO SET THE TOOL EVERY MINUTE FOR 20 MINUTES. WHEN LINE WAS PULLED INTO TENSION, WE PULLED OUT OF THE ROPE SOCKET AT 3000 LBS. TOOH W/ NO TOOL STRING. WAIT ON NEW TOOLS.
	16:30 - 17:30	1.00	ABANDP	34	I	P		PU AND RIH W/ CCL, SETTING TOOL, AND 5-1/2" CIBP. SET CIBP @ 7835'. PUH AND RIH TO STACK OUT TO CONFIRM PLUG IS SET. RDMO RELIANCE WL. SWI. SDFN.
	17:30 - 18:15	0.75	ABANDP	30	G	P		CREW TRAVEL FROM LOCATION.
6/29/2016	6:15 - 7:00	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.
	7:00 - 7:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. STAY OUT FROM BEHIND THE WL TRUCK WHEN RUNNING IN AND OUT OF THE HOLE. WATCH FOR PINCH POINTS WHEN TRIPPING PIPE.
	7:15 - 7:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN THE REST OF THE DAY. SI AT THE END OF THE DAY.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	7:15 - 9:00	1.75	ABANDP	31	I	P		TIH W/ 252 JTS DOWN TO 7835' AND TAG CIBP @ 7835'.
	9:00 - 10:00	1.00	ABANDP	31	H	P		PUH AND LD 1 JT. LOAD THE HOLE W/ 150 BBLS OF BIOCIDED TREATED FRESH WATER. CIRCULATE ALL GAS OUT OF THE WELL PUMPING AT 2.5 BBLS/MIN AND 200 PSI ON AVERAGE.
	10:00 - 11:30	1.50	ABANDP	31	I	P		TOOH AND SB 214 JTS AND LD 40 JTS OF 2-3/8" TBG.
	11:30 - 13:30	2.00	ABANDP	41	A	P		MIRU RELIANCE WL. HAVE PRE-JOB SAFETY MEETING TO TALK ABOUT THE DAYS OPERATIONS. PU AND RIH W/ LOGGING TOOLS. CORRELATE CBL TO THE GR OF AN OH LOG RUN BY DJ BASIN PERFORATION (1/8/79). RUN CBL FROM 7830' TO SURFACE. TOC: 6924'. LD LOGGING TOOLS.
	13:30 - 13:45	0.25	ABANDP	52	F	P		PT CIBP TO 1000 PSI FOR 15 MINUTES. GOOD TEST. NO BLEED OFF.
	13:45 - 14:45	1.00	ABANDP	34	D	P		PU DUMP BAILER. MIX AND POUR 2 SX OF CMT INTO DUMP BAILER AND RIH DOWN TO 7835' AND DUMP 2 SX. POOH. LD DUMP BAILER.
	14:45 - 15:15	0.50	ABANDP	34	H	P		PU PERFORATION GUNS, 3 SPF, 120" PHASING, 0.7" EHD AND SHOOT 2' OF HOLES AT 6780' AND 4' OF HOLES AT 6660'. POOH, LD GUNS. CONFIRM ALL SHOTS FIRED. RD MO RELIANCE WL. SWI. SDFN.
	15:00 - 15:45	0.75	ABANDP	30	G	P		CREW TRAVEL FROM LOCATION.
6/30/2016	6:15 - 7:00	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.
	7:00 - 7:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. STAY AWAY FROM CMT LINES WHEN PUMPING. WATCH FOR PINCH POINTS WHEN TRIPPING PIPE.
	7:15 - 7:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 5 PSI - NO FLUID. BLOW DEAD IN 30 SEC. LEAVE OPEN THE REST OF THE DAY. SI AT THE END OF THE DAY.
	7:15 - 10:15	3.00	ABANDP	31	I	P		MIRU HYDROTESTER. PU 5-1/2", 17# CICR ON 2-3/8" TBG AND HYDROTEST 215 JTS TO 4000 PSI DOWN TO 6690'. SET CICR. RD HYDROTESTER.
	10:15 - 12:00	1.75	ABANDP	31	H	P		ESTABLISH INJECTION AND CIRCULATION W/ BIOCIDED TREATED FRESH WATER. PUMP 200 BBLS AT 600 PSI AND 2 BBLS/MIN. GOOD CIRCULATION THROUGHOUT.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	12:00 - 13:30	1.50	ABANDP	51	D	P		MIRU SLB. HOLD JSA TO TALK THROUGH OPERATIONS. SET MAX PRESSURE AT 2000 PSI. PRESSURE TEST LINES TO 2500 PSI FOR 3 MINUTES. PUMP 15 BBLs CHEM WASH, 72 SX (19.9 BBLs) OF 15.8 PPG, 1.55 YLD CLASS G CEMENT. DISPLACE CMT W/ 20.8 BBLs OF FRESH WATER. STING OUT AND LEAVE 5 BBLs OF CMT ON TOP OF CIRC, PUMPED AT AVERAGE OF 400 PSI AND 2.2 BBL/MIN. GOOD CIRCULATION THROUGHOUT JOB. RDMO SLB.
	13:30 - 16:00	2.50	ABANDP	31	I	P		TOOH, SB 30 STANDS. RU CIRCULATION EQUIPMENT. EOT @ 4820'. REVERSE CIRCULATE 60 BBLs TO MAKE SURE TBG IS CLEAN. SB 43 MORE STANDS. LD 69 JTS OF 2-3/8" TBG. SWI. SDFN. CREW TRAVEL FROM LOCATION.
7/1/2016	16:00 - 16:45	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION
	6:00 - 6:45	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION
	6:30 - 6:45	0.25	ABANDP	48	B	P		JSA W CREW, CHECK PRESSURES 0# ON CSG
	7:00 - 8:00	1.00	ABANDP	34	H	P		SPOT IN RIG UP RELIANCE WIRELINE, PU & RIH W 2 3 1/8" PERF GUNS W 3SPF, .5 EHD, 120 DEGREE, 2' OF HOLES @ 4750', 4' OF HOLES @ 4540', POOH, LD PREF GUNS, RDMO RELIANCE
	7:00 - 7:00	0.00	ABANDP	52	I	P		SURFACE CASING PRESSURE-0#, LEAVE OPEN FOR DURATION OF WORK DAY, SHUT IN AT THE END OF DAY
	8:00 - 9:00	1.00	ABANDP	31	I			PU 5 1/2' CIRC TIH FROM DERRICK W 147JTS OF 2 3/8" 4.7# J55 & SET CIRC @ 4570'
	9:00 - 12:00	3.00	ABANDP	31	H	P		USING RIG PUMP ESTABLISH CIRCULATION, PUMPING @ 600PSI 2BPM CIRCULATE 200BLLS OF FRESH WATER W BIO
	12:00 - 13:00	1.00	ABANDP	51	A	P		SPOT IN RU SCHLUMBERGER ONTO TUBING, HOLD SAFETY MEETING W ALL PERSONS ON LOCATION, PROCEED TO PUMP SUSSEX SQUEEZE MAX PRESSURE 2000PSI TEST LINES TO 2500PSI 10BBL SODIUM METICILICATE 165SX CEMENT @ 15.8PPG 1.18 YIELD DISPLACE 12.7BBL AVG PRESSURE-448PSI AVG BPM-3 RD SHLUMBERGER
	13:00 - 14:30	1.50	ABANDP	31	I	P		TOOH LD ON TUBING FLOAT W 12JTS OF 2 3/8" 4.7#, RU KELLY HOSE ONTO TUBING, REVERSE CIRCULATE TO CLEAN UP TUBING USING RIG PUMP
	14:30 - 16:00	1.50	ABANDP	31	I			CONTINUE TO TOOH TO DERRICK W 44JTS OF 2 3/8" 4.7#, LD ON FLOAT REMAINING 91JTS, SIW, CHANGE OUT
	16:00 - 16:45	0.75	ABANDP	30	G	P		CREW TRAVEL
7/5/2016	6:15 - 7:00	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	7:00 - 7:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. STAY AWAY FROM TEH BACK OF WL WHILE THEY ARE RUNNING IN AND OUT OF THE HOLE. WATCH FOR PINCH POINTS WHEN TRIPPING PIPE. STAY IN CONSTANT COMMUNICATION WHEN UNLANDING CSG.
	7:15 - 7:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN ALL DAY. SI AT THE END OF THE DAY.
	7:15 - 8:45	1.50	ABANDP	34	L	P		MIRU RELIANCE WL. HAVE JSA AND TALK ABOUT THE DAYS OPERATIONS. RU LUBRICATOR. PU AND RIH W/ 15 CHARGE SPLIT SHOT TO CUT CSG. RIH DOWN TO COLLAR AT 1297' AND FIRE SPLIT SHOT. TOOH AND CONFIRM ALL SHOTS FIRED. RD RELIANCE WL.
	8:45 - 10:00	1.25	ABANDP	31	H	P		ATTEMPT TO CIRCULATE THE WELL. PUMP 20 BBLS AT 2 BBL/MIN AND 200 PSI WITH POOR CIRCULATION. AFTER 20 BBLS AWAY PRESSURE DROPPED TO 0 PSI AND SAW NO MORE RETURNS. SHUT DOWN, FLOW BACK 5 BBLS. ATTEMPT TO ESTABLISH CIRCUALTION AGAIN WITH NO SUCESS.
	10:00 - 12:00	2.00	ABANDP	31	1	X		ATTEMPT TO UNLAND 5-1/2" CSG. PULL 80,000 LBS MAX AND UNLAND CSG. COULD NOT GET THE SLIPS TO COME UP WITH THE CASING THOUGH. RELAND CSG IN SLIPS AND COULD NOT GET THE SLIPS OUT. DUE TO THE WH STYLE, WE NEEDED TO CUT OFF THE 4" WE MOVED THE CSG.  CONTACT ON CALL ENGINEER AND DISCUSS WHAT PLANS TO MAKE GOING FORWARD. <b>DECIDE TO SHOOT SQUEEZE HOLES BELOW THE CUT AND TURN THE NEXT CMT JOB INTO A SUICIDE SQUEEZE INSTEAD.</b>
	12:00 - 13:00	1.00	ABANDP	53	C	S		MIRU WELDER. CUT OFF 4" PIECE OF 5-1/2" CSG THAT WAS STRETCHED FROM UNLANDING ATTEMPT. TACK WELD SLIPS TO CSG FOR NEXT CUT ATTEMPT. NU WH AND BOPS TO CSG HEAD.
	13:00 - 14:00	1.00	ABANDP	34	H	S		<b>RU RELIANCE WL AND LUBRICATOR. PU AND TIH W/ PERFORATION GUNS. SHOOT 4' OF 3 SPF, 120*, 0.7" EHD AT 1600'. PUH SHOOT 2' OF 3 SPF, 120*, 0.7" EHD AT 1300'.</b> TOOH AND CONFIRM ALL SHOTS FIRED.
	14:00 - 15:00	1.00	ABANDP	31	I	S		PU 5-1/2" TENSION SET PKR AND UNLOADER ON 2-3/8" TBG. TIH AND SET <b>PKR AT 1340'</b> W/ 43 JTS.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	15:00 - 16:00	1.00	ABANDP	31	H	S		ESTABLISH CIRCULATION DOWN TBG UP CSG AT 2 BBLs/MIN AND 300 PSI. GETTING ALMOST FULL RETURNS FOR 20 MINUTES AND THEN RETURNS SLOWED AND STOPPED. PUMP DOWN CSG AND UP TBG TO TRY AND CLEAR UP ANY PLUGGED OFF SQUEEZE HOLES. ESTABLISH CIRCULATION AGAIN BUT WITHOUT FULL RETURNS. RETURNS ARE A MIX OF MUD AND WATER. CIRCULATE 140 BBLs TOTAL. CREW TRAVEL FROM LOCATION.
	16:15 - 17:00	0.75	ABANDP	30	G	P		
	16:15 - 16:30	0.25	ABANDP	31	I	S		RELEASE PKR AND TOO. SB 21 STANDS OF 2-3/8" TBG AND LD 1 JT. SWI. SDFN
7/6/2016	6:15 - 7:00	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.
	7:00 - 7:15	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT INTO LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. STAY AWAY FROM THE BACK OF WL WHILE THEY ARE RUNNING IN AND OUT OF THE HOLE. WATCH FOR PINCH POINTS WHEN TRIPPING PIPE. STAY IN CONSTANT COMMUNICATION WHEN UNLANDING CSG. STAY AWAY FROM LINES WHEN PUMPING CMT.
	7:15 - 7:15	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN ALL DAY. SI AT THE END OF THE DAY.
	7:15 - 7:45	0.50	ABANDP	31	I	P		PU AND TIH W/ 5-1/2" CICR AND 43 JTS OF 2-3/8" TBG DOWN TO 1340'. SET CICR. STING OUT AND STING BACK INTO CICR.
	7:45 - 9:30	1.75	ABANDP	31	H	P		RU CIRCULATION EQUIPMENT AND KELLY HOSE. CIRCULATE THE WELL W/ 150 BBLs. PUMP 2 BBL/MIN AND 100 PSI WITH GOOD CIRCULATION. RD CIRCULATION EQUIPMENT.
	9:00 - 10:30	1.50	ABANDP	51	D	P		MIRU SLB CEMENTING. HAVE PRE JOB SAFETY MEETING AND DISCUSS THE DAYS OPERATIONS. SET MAX PRESSURE AT 1500 PSI. PRESSURE TEST LINES TO 2500 FOR THREE MINUTES. PUMP 15 BBLs CHEM WASH, 257 SX (54 BBLs), 1.18 YLD, 15.8 PPG CLASS G CMT AT AVERAGE OF 500 PSI AND 1.9 BBL/MIN. DISPLACE W/ 0.5 BBLs OF FRESH WATER. STING OUT OF THE CICR AND LEAVE 5 BBLs OF CMT ON CICR.
	10:30 - 12:00	1.50	ABANDP	31	I	P		TOOH AND LD 16 JTS OF 2-3/8" TBG. EOT @ 841'. RU SLB HOSE TO TBG AND WASH UP 10 BBLs AND CIRCULATE 40 BBLs OF FRESH WATER. GET 5 BBLs CMT BACK TO TANK. CIRCULATE CLEAN. TOOH, LD ONE JT AND SB ALL REMAINING TBG. RDMO SLB CEMENTING.

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1

Spud date: 11/11/1978

Project: COLORADO-ADAMS-NAD83-UTM13

Site: CHAMPLIN 078 AMOCO "D" #1

Rig name no.: BASIC 1549/1549

Event: ABANDONMENT

Start date: 6/27/2016

End date:

Active datum: RKB @5,072.99usft (above Mean Sea Level)

UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
7/7/2016	12:00 - 12:45	0.75	ABANDP	34	L	P		MIRU RELIANCE WL. HAVE JSA AND DISCUSS OPERATIONS. RU LUBRICATOR AND EQUIPMENT. RIH W/ 5-1/2", 14# JET CUT DOWN TO 744'. CUT CSG. TOOH AND LD JET CUT TOOL. RDMO RELIANCE WL.
	12:45 - 13:15	0.50	ABANDP	31	H	P		RU CIRCULATION EQUIPMENT AND ATTEMPT TO CIRCULATE THROUGH THE CSG CUT. PUMP 40 BBLs AT 1.5 BBLs/MIN AND 500 PSI. VERY POOR CIRCULATION. ONLY TRICKLED INTO TANK. RD CIRC EQUIPMENT.
	13:15 - 15:15	2.00	ABANDP	31	1	P		CHANGE OVER EQUIPMENT TO PULL 5-1/2" CSG. PIPE RAMS, ELEVATORS, TONGS AND SLIPS.
	15:15 - 16:45	1.50	ABANDP	31	I	P		SPEAR CSG AND UNLAND CSG AT 50,000 LBS. PULL AND LD 734' (20 JTS) OF 5-1/2", 14# CSG ON THE TRAILER.
	16:45 - 17:15	0.50	ABANDP	31	1	P		CHANGE OVER EQUIPMENT TO RIH 2-3/8" TBG. PIPE RAMS, ELEVATORS, TONGS AND SLIPS. SWI. SDFN.
	17:15 - 17:15	0.00	ABANDP	30	G	P		CREW TRAVEL FROM LOCATION.
	6:00 - 6:45	0.75	ABANDP	30	G	P		CREW TRAVEL TO LOCATION.
	6:45 - 7:00	0.25	ABANDP	48	B			MORNING SAFETY MEETING/JSA RIG CREW - TALK THROUGH THE DAYS OPERATIONS. TALK ABOUT THE WARM WEATHER AND TO MAKE SURE AND STAY HYDRATED. USE GOOD COMMUNICATION AND HAND SIGNALS WHEN MOVING EQUIPMENT OUT OF LOCATION. USE WINCH LINE WHEN HANDLING TOOLS UP TO THE RIG FLOOR. KEEP EYES ON WHEN TRANSFERING FLUID AND BREAKING LINES. TALKED THROUGH OUR EMERGENCY RESPONSE PROTOCOL. WATCH FOR PINCH POINTS WHEN TRIPPING PIPE.
	7:00 - 7:00	0.00	ABANDP	52	I	P		BRADENHEAD PRESSURE @ 0 PSI - NO FLUID. LEAVE OPEN ALL DAY. SI AT THE END OF THE DAY.
	7:00 - 7:15	0.25	ABANDP	31	I	P		PU AND TIH W/ 27 JTS OF 2-3/8" TBG DOWN TO 840'.
	7:15 - 9:15	2.00	ABANDP	31	H	P		RU CIRCULATION EQUIPMENT. CIRCULATE 240 BBLs OF BIO WATER AT 2 BBLs/MIN AND 200 PSI TO CLEAN THE HOLE UP. GOOD CIRCULATION THROUGHOUT.
	9:15 - 10:45	1.50	ABANDP	51	D	P		MIRU SLB CEMENTING. HOLD JSA AND SAFETY MEETING. DISCUSS PUMPING PROCEDURE. PRESSURE TEST LINES TO 2500 PSI FOR 3 MINUTES. SET MAX PRESSURE AT 1500 PSI. PUMP 285 SX (59.5 BBL), 1.17 YLD, 15.8 PPG CLASS G CMT AT AVERAGE OF 200 PSI AND 2.4 BBL/MIN. SAW CMT TO THE TANK AFTER 56 BBLs. PUMPED OFF THE REST OF THE MIXED CMT. DISPLACED 0.5 BBLs FRESH WATER TO CLEAR LINES. BLED OFF PRESSURE.
	10:45 - 11:45	1.00	ABANDP	31	I	P		TOOH AND LD 26 JTS OF 2-3/8" TBG ON THE TRAILER. RU SLB PUMP AND WASH UP W/ ONE JT IN THE HOLE. CIRCULATE ALL EQUIPMENT CLEAN. TOOH AND LD ALL TBG. RDMO SLB CEMENTING.
	11:45 - 13:30	1.75	ABANDP	30	C	P		RD SURFACE LINES AND EQUIPMENT. ND BOPS. RDMO BASIC 1549 TO DREYER 2.
7/20/2016	10:00 - 11:00	1.00	ABANDP	53	B	P		DUG UP SUFACE CASING

US ROCKIES REGION  
Operation Summary Report

Well: CHAMPLIN 78 AMOCO D 1			Spud date: 11/11/1978		
Project: COLORADO-ADAMS-NAD83-UTM13		Site: CHAMPLIN 078 AMOCO "D" #1		Rig name no.: BASIC 1549/1549	
Event: ABANDONMENT		Start date: 6/27/2016		End date:	
Active datum: RKB @5,072.99usft (above Mean Sea Level)			UWI: 0/1/S/65/W/5/0/SWNE/6/0/0/0/0/0/0/0		

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	11:00 - 12:00	1.00	ABANDP	53	C	P		CUT CASING 6' BELOW GL, TAGGED @ 34' IN SURFACE CASING
	12:00 - 13:00	1.00	ABANDP	53	B	P		FILLED SURFACE CASING W 15 BAGS OF 5000PSI CEMENT
	13:00 - 14:00	1.00	ABANDP	53	A	P		CAPPED CASIN W A METAL PLATE CONTAINING WELL INFO
	14:00 - 15:00	1.00	ABANDP	53	B	P		BACKFILLED