

Little Will #9
05-123-12238
P&A Procedure

SWSE Section 25 T6N R65W

KB: 4661'

Weld County, CO

TD: 7009' KB



GL: 4650'

Surface Casing: 8 5/8" 24#/ft set @ 322' KB, cmt to surf

Prod Casing: 4 1/2", 11.6#/ft, set @ 6989' KB (TOC 2,394')

- 1) Perform Bradenhead test as per state requirements and COA. Sample any fluid or gas present on bradenhead and provide to the state.
- 2) MIRU workover rig, pump and tank
- 3) PU 2 3/8" work string, RIH with bit & scraper to +/- 6,925'
- 4) POOH with tubing, bit and scraper
- 5) MIRU WL Unit
- 6) RIH with CIBP & set @ 6,875', Dump Bail 2 sacks of Cement on plug
- 7) RIH with CIBP & set @ 3,540', Dump Bail 2 sacks of Cement on plug
- 8) RDMO WL Unit
- 9) RIH with TBG to 650', cement to surface with 50 sacks of cement.
- 10) RDMO location with workover rig
- 11) Dig up and cut casing below surface, weld on dry hole marker