

Little Will #2
05-123-11419
P&A Procedure

NWSE Section 25 T6N R65W

KB: 4670'

Weld County, CO

Logger TD: 7198' KB



GL: 4663'

Surface Casing: 8 5/8" 24#/ft set @ 258' KB, cmt to surf

Prod Casing: 4 1/2", 10.5#/ft, set @ 6989' KB (TOC 3,230')

- 1) Perform Bradenhead test as per state requirements and COA. Sample any fluid or gas present on bradenhead and provide to the state.
- 2) MIRU workover rig, pump and tank
- 3) PU 2 3/8" work string, RIH with bit & scraper to +/- 6,925'
- 4) POOH with tubing, bit and scraper
- 5) MIRU WL Unit
- 6) RIH with CIBP & set @ 6,900', Dump Bail 4 sacks of Cement on plug
- 7) RIH with CIBP & set @ 3,525', Dump Bail 4 sacks of Cement on plug
- 8) RDMO WL Unit
- 9) RIH with TBG to 650', cement to surface with 50 sacks of cement.
- 10) RDMO location with workover rig
- 11) Dig up and cut casing below surface, weld on dry hole marker