

#### **Anschutz Equus Farms 4-62-20-0108C2B P&A Procedure**

---

- 1 MIRU
- 2 RIH and set bridge plug @ 7,001' MD
- 3 Fill the hole with fresh water
- 4 Unsting tieback string from liner top pbr
- 5 RU cementers
- 6 Pump 100' cement plug from 5,900' - 5,800' MD
- 7 POOH, laying down 4 1/2" casing to 908' MD
- 8 Pump 100' cement plug from 908' - 808' MD
- 9 POOH, laying down 4 1/2" casing to 100' MD
- 10 Pump 100' cement plug from 100' MD - surface
- 11 RD cementers and workover rig
- 12 Cut off wellhead and riser to 4' below ground level
- 13 Weld on dry hole marker
- 14 Clean location and move out