

Document Number:  
401157166

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Kelsi Welch  
 Name of Operator: PDC ENERGY INC Phone: (303) 831-3974  
 Address: 1775 SHERMAN STREET - STE 3000 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80203 Email: kelsi.welch@pdce.com

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277  
 COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-13981-00 Well Number: 43-16  
 Well Name: STATE LEASE 81  
 Location: QtrQtr: NESE Section: 16 Township: 6N Range: 64W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: 67845  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.484690 Longitude: -104.548250  
 GPS Data:  
 Date of Measurement: 12/07/2008 PDOP Reading: 2.0 GPS Instrument Operator's Name: Holly L. Tracy  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6986	6998			
FORT HAYS	6957	6982			
NIOBRARA	6693	6910			

Total: 3 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	315	175	315	0	CBL
1ST	7+7/8	4+1/2	11.6	7,160	220	7,160	6,230	CBL
S.C. 1.1				5,494	275	5,494	3,540	CBL
S.C. 1.2				936	430	936	0	VISU

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6643 with 2 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 5600 ft. to 5070 ft. Plug Type: CASING Plug Tagged:   
 Set 90 sks cmt from 936 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

State Lease 81 43-16 (05-123-13981)/Plugging Procedure (Intent)  
 Producing Formation: Niobrara: 6693'-6910'  
 Ft. Hays: 6957'-6982'  
 Codell: 6986'-6998'  
 TD: 7160' PBTD: 7100'  
 Surface Casing: 8 5/8" 24# @ 315' w/ 175 sxs  
 Production Casing: 4 1/2" 11.6# @ 7160' w/ 220 sxs cmt (TOC 6230' - CBL)  
 Casing patch at 5500' with 275 sxs, (TOC 3540' - CBL)  
 Annular cement job 430 sxs (TOC at surface)

Tubing: 2 3/8" tubing set at 6968'. (7/10/2007)

**Proposed Procedure:**

1. MIRU RU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company. Run Gyro Survey from 7000' to surface.
3. TIH with CIBP. Set CIBP at 6643'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with tubing to 5600'. Mix and pump 40 sxs of 15.8#/gal CI G cement down tubing.
5. TIH with tubing to 936'. Mix and pump 90 sxs of 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
6. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Kelsi Welch  
 Title: Production Tech Date: \_\_\_\_\_ Email: kelsi.welch@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

<u>COA Type</u>	<u>Description</u>

**Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
401174022	WELLBORE DIAGRAM
401174027	WELLBORE DIAGRAM

Total Attach: 2 Files

**General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)