

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 401217097			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>100322</u>	Contact Name: <u>Sonu Choudhary</u>
Name of Operator: <u>NOBLE ENERGY INC</u>	Phone: <u>(303) 228-4302</u>
Address: <u>1625 BROADWAY STE 2200</u>	Fax: _____
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80202</u>	Email: <u>narayan.choudhary@nblenergy.com</u>
For "Intent" 24 hour notice required, Name: <u>Peterson, Tom</u> Tel: <u>(303) 815-9641</u>	
COGCC contact: Email: <u>tom.peterson@state.co.us</u>	

API Number <u>05-123-16262-00</u>	Well Name: <u>MOSER</u>	Well Number: <u>34-6G</u>
Location: QtrQtr: <u>SENW</u> Section: <u>34</u> Township: <u>4N</u> Range: <u>65W</u> Meridian: <u>6</u>		
County: <u>WELD</u>	Federal, Indian or State Lease Number: <u>66522</u>	
Field Name: <u>WATTENBERG</u>	Field Number: <u>90750</u>	

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.272010 Longitude: -104.653580

GPS Data:
Date of Measurement: 07/24/2006 PDOP Reading: 2.1 GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 650

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7103	7120			
J SAND	7605	7626			
NIOBRARA	6828	6918			
SUSSEX	4429	4460	01/09/2005	SQUEEZED	

Total: 4 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	533	265	533	11	VISU
1ST	7+7/8	4+1/2	11.6	7,931	450	7,931	6,218	CBL
S.C. 1.1				4,765	300	4,765	4,050	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7555 with 2 sacks cmt on top. CIBP #2: Depth 6778 with 2 sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 4550 ft. to 3900 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 2500 ft. with 200 sacks. Leave at least 100 ft. in casing 2400 CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 (Cast Iron Cement Retainer Depth)

Set 213 sacks half in. half out surface casing from 700 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Stephanie Dionne
 Title: Engineering Tech Date: _____ Email: stephanie.dionne@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type	Description

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401217101	WELLBORE DIAGRAM
401217102	PROPOSED PLUGGING PROCEDURE
401217103	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)