

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: <b>401245377</b>			
Date Received:			

**SUNDRY NOTICE**

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name CHERYL LIGHT  
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461  
 Address: P O BOX 173779 Fax: (720) 929-7461  
 City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- 123 25727 00 OGCC Facility ID Number: 295490  
 Well/Facility Name: WATERFRONT Well/Facility Number: 8-34  
 Location QtrQtr: SWNE Section: 34 Township: 3N Range: 68W Meridian: 6  
 County: WELD Field Name: WATTENBERG  
 Federal, Indian or State Lease Number: \_\_\_\_\_

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

**CHANGE OF LOCATION OR AS BUILT GPS REPORT**

- Change of Location \*       As-Built GPS Location Report       As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

**SURFACE LOCATION GPS DATA** Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
 Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

**LOCATION CHANGE (all measurements in Feet)**

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

FNL/FSL		FEL/FWL	
<input type="text" value="1473"/>	<input type="text" value="FNL"/>	<input type="text" value="1454"/>	<input type="text" value="FEL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr  Sec  Twp  Range  Meridian   
 New **Surface** Location **To** QtrQtr  Sec  Twp  Range  Meridian

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

<input type="text" value="2093"/>	<input type="text" value="FNL"/>	<input type="text" value="597"/>	<input type="text" value="FEL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec  Twp  Range

<input type="text" value="2093"/>	<input type="text" value="FNL"/>	<input type="text" value="597"/>	<input type="text" value="FEL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

New **Top of Productive Zone** Location **To** Sec  Twp  Range

Change of **Bottomhole** Footage **From** Exterior Section Lines:

<input type="text" value="2093"/>	<input type="text" value="FNL"/>	<input type="text" value="597"/>	<input type="text" value="FEL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec  Twp  Range

<input type="text" value="2093"/>	<input type="text" value="FNL"/>	<input type="text" value="597"/>	<input type="text" value="FEL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

New **Bottomhole** Location Sec  Twp  Range

\*\* attach deviated drilling plan

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,  
 property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_



Comments:

## ENGINEERING AND ENVIRONMENTAL WORK

### NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

SPUD DATE: \_\_\_\_\_

## TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

NOTICE OF INTENT Approximate Start Date 04/07/2017

REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

1 Well needs a retainer squeeze from 950'-550' for bradenhead issues.  
2 Well has gyro survey on 5/14/2008.  
3 MIRU Slickline. Pull bumper spring and tag bottom. Record tag depth in Open Wells. RD slickline.  
4 Prepare location for base beam equipped rig. Install perimeter fence as needed.  
5 Check and record bradenhead pressure. If bradenhead valve is not accessible, re-plumb so that valve is above GL. Blow down bradenhead and re-check pressure the next day. Repeat until pressure stays at 0 psi.  
6 MIRU WO rig. Spot 25 jts of 2-3/8" 4.7# J-55 tbg.  
7 Kill well as necessary with water and biocide. Attach a hardline from the bradenhead/surface casing valve to a flowback tank and blow down any Bradenhead pressure. If pressure does not blow down within 1 hour contact engineer, otherwise proceed.  
8 ND wellhead. NU BOP.  
9 PU 8-10' pup joint with TIW valve on top and screw into the tbg hanger. Unseat and LD the landing joint.  
10 MIRU EMI services. EMI 2-3/8" tbg (~233 jts landed at 7366') while TOO H and tally while standing back. Lay down joints that have greater than 35% penetration or wall loss. Replace all joints that fail EMI testing. Document joint numbers and depth of bad tubing and create a Production Equipment Failure report in OpenWells. RDMO EMI services.  
11 MIRU WL. PU and RIH with (4.5", 11.6#) Gauge Ring to 7120'. POOH.  
12 PU and RIH with (4.5", 11.6#) CIBP. Set CIBP at +/- 7110'. POOH. SB WL.  
13 TIH with 2-3/8" tbg to 2500'. Pumping water with biocide, pressure test CIBP and production casing to 2000 psi for 15 minutes. If test fails, contact Engineering.  
14 TOO H and SB 2-3/8" tubing.  
15 PU and RIH with one 1' 3-1/8" perf gun with 3 spf, 0.50" EHD, 120° phasing. Shoot 1' of squeeze holes at 950'. POOH. RD WL.  
16 Establish circulation to surface with biocide treated fresh water. If rate is less than 1 bpm at 1000 psi, contact engineer.  
17 PU and RIH with (4.5", 11.6#) CICR on 2-3/8" tbg while hydrotesting to 4000 psi and set at 920'. Establish circulation through squeeze holes with biocide treated fresh water and circulate a minimum of 200 bbls through squeeze holes.  
18 MIRU cementing services. Establish circulation and pump 20 bbl (5 bbls of water, 10 bbls of sodium silicate, and 5 bbls water) spacer, GASBLOK cement 125 sx (145 cf) 15.8 ppg 1.16 yield. Underdisplace by 1 bbl. (based on 30' below retainer in 4-1/2" casing, 6.13" hole size + 60% excess from 950'-905' and from 905' to 550' between 8-5/8" 24# surface casing and 4-1/2" 11.6# production casing). Attempt to cement from 950'-550'.  
19 PUH to 400' and reverse circulate tubing clean to ensure no cement is left in the tubing. Reverse circulate until no cement in returns. TOO H. SB ALL tbg. LD stinger. WOC 24 hours.  
20 PU and TIH with 3-7/8" bit and appropriate number of 3-1/2" drill collars on 2-3/8" tbg. Time drill cement above CICR (~65'). If rate of penetration is faster than 2 min/ft, SD and WOC 24 hours and repeat. Drill down to the CICR located at +/-920'. Drill CICR and cement past lower perf at 950' and pressure test to 500 psi for 5 minutes.  
21 TOO H. SB tbg and drill collars, LD bit.  
22 MIRU wireline and run CCL-GR-CBL-VDL from +/- 4000' (below the original TOC) to surface. Forward to Engineering. RDMO wireline services. In addition to normal handling, of logs/job summaries, email copies of all cement job logs/job summaries and invoices to DJVendors@anadarko.com within 24 hrs of the completion of the job.  
23 PU and TIH with bit and drill collars on 2-3/8" tubing. Drillout CIBP at 7110' and chase down to 7500'.  
24 TOO H. SB tbg. LD drill collars and bit.  
25 PU 2-3/8" NC, 2-3/8" XN nipple (be sure to correctly input into OpenWells), ~9 jts of 2-3/8" tbg (to set packer at 7100'), 4-1/2" Arrowset AS-1X packer (10K psi rated above and below), and 2-3/8" 4.7# J-55 tbg to surface while hydrotesting to 5000 psi. Land EOT at +/- 7380' (1 jt above Codell perms).

**CASING AND CEMENTING CHANGES**

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

**H2S REPORTING**

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

<b><u>Best Management Practices</u></b>	
<b><u>No BMP/COA Type</u></b>	<b><u>Description</u></b>

**Operator Comments:**

26 Set packer at +/- 7100'. Load backside with packer fluid and test to 500 psi.  
 27 RU rig lubricator. Broach tubing to XN seating nipple. RD rig lubricator. ND BOP.  
 28 Install 7-1/16" flanged 5000 psi tubing head adaptor with studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). Make sure all wellhead valves are rated to 5,000 psi. Document wellhead components in an OpenWells wellhead report.  
 29 Install 2-3/8" pup joint above the master valve. Pressure test the tubing head from below the tubing head through the master valve to 5,000 psi using hydrotester. If wellhead does not pressure test, replace wellhead/ wellhead valves as necessary with 5,000 psi rated equipment.  
 30 NU WH. RDMO WO rig. Return well to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: CHERYL LIGHT  
 Title: SR REGULATORY ANALYST Email: DJREGULATORY@ANADARKO.COM Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

<u>COA Type</u>	<u>Description</u>

**General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)

**Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
401245384	OTHER
401245386	WELLBORE DIAGRAM

Total Attach: 2 Files